



# Gen IV iAC Controller Operation Manual



# Table of Contents

<b>1. Safety Information</b>	<b>3</b>	4.5.10 Lock Tool on Reject.	32
<b>2. Controller Diagram</b>	<b>4</b>	4.5.11 Languages	32
2.1 Bottom Panel iAC Basic Model	4	<b>4.6 Accessories</b>	<b>32</b>
2.2 Bottom Panel iAC Models with Shutoff Valve and/or Regulator	4	<b>4.7 Diagnostics</b>	<b>32</b>
2.3 Top Panel iAC Models with Shutoff Valve and/or Regulator	5	4.7.1 Controller Overview	32
2.4 Front Console LED Display	5	4.7.2 Controller Status	33
<b>3. Initial Setup</b>	<b>6</b>	4.7.3 Live Tool	33
3.1 Air and Electrical Connections	6	4.7.4 Indicators	33
3.2 Interfacing with the Controller	7	4.7.5 Identify Controller	34
3.3 Enter Tool Information into the Controller	9	4.7.6 Record Logs	34
3.4 Quick Set Up (Default PSets from Tool)	9	4.7.6.1 Change Log	34
<b>4. Home Page (Main Menu)</b>	<b>10</b>	4.7.6.2 Information Log	34
4.1 Run	10	4.7.6.3 Error Log	34
4.2 PSet	12	4.7.6.4 All	34
4.2.1 Add New PSet	12	4.7.7 System Status	34
4.2.1.1 Add New Stage	12	4.7.8 I/O Diagnostics	34
4.2.2 PSet Stages	13	4.7.9 Network Diagnostics	34
4.2.2.1 TC_PM Torque Control Pulse Monitor	13	4.7.10 Statistics	35
4.2.2.2 TC_APM Torque Control Angle Pulse Monitor	14	<b>4.8 Login</b>	<b>35</b>
4.2.2.3 TC_AM Torque Control Angle Monitor	15	<b>4.9 Advanced</b>	<b>35</b>
4.2.2.4 AC_TM Angle Control Torque Monitor	15	4.9.1 Login Setup	35
4.2.3 Edit PSet	16	4.9.2 Results Archive	36
4.2.4 Advanced Options	16	4.9.3 Import Settings	36
4.2.5 Default Psets	17	4.9.4 Export Controller	37
4.2.6 Manage Psets	17	4.9.5 Update Controller	37
4.2.7 Multistage Rundown Evaluation and Reporting	18	4.9.6 Backup Restore	37
4.3 Job	18	4.9.7 Restore Factory Defaults	38
4.3.1 Add New Job	18	4.9.8 Previous Software	38
4.3.2 Advanced Options	19	4.9.9 Calibrate Touch Screen	38
4.3.3 Jobs "Enabled" Display and Button Function	19	4.9.10 Soft Reboot	39
4.4 Results	20	<b>5. Barcode Reader Details</b>	<b>40</b>
4.4.1 Saving Rundown(s)	20	<b>6. Glossary of Terms</b>	<b>42</b>
4.5 Controller	22	<b>7. Icons Defined</b>	<b>43</b>
4.5.1 Tool Setup	22	<b>8. Stop Codes</b>	<b>44</b>
4.5.1.1 Tool Parameters	22	<b>9. Error Codes</b>	<b>45</b>
4.5.1.2 Disassembly	23	<b>10. 24 Volt I/O</b>	<b>46</b>
4.5.1.3 Lock Tool On Reject	23	<b>11. Assignable I/O</b>	<b>48</b>
4.5.2 IO	24	<b>12. Controller Supported MIDs</b>	<b>60</b>
4.5.2.1 Physical IO	24	<b>13. Dimensions</b>	<b>61</b>
4.5.2.2 Physical IO Monitor	24	<b>14. Specifications</b>	<b>61</b>
4.5.2.3 Anybus/Modbus TCP/Ethernet IP Inputs	25	<b>15. Troubleshooting</b>	<b>62</b>
4.5.2.4 Anybus/Modbus TCP/Ethernet IP Outputs	26	<b>16. AIMCO Warranty</b>	<b>63</b>
4.5.3 Communication Interfaces	27		
4.5.3.1 Ethernet/Second Ethernet	27		
4.5.3.2 System Port	27		
4.5.3.3 Serial Port	27		
4.5.3.4 Anybus	28		
4.5.3.5 Spindle USB Port	28		
4.5.3.6 Serial USB	28		
4.5.4 Protocols	30		
4.5.5 Front Panel Buttons	30		
4.5.6 Power Up	30		
4.5.7 Bar Code Setup	30		
4.5.8 Set Time	31		
4.5.9 Remote Connections	31		

## 1. Safety Information

### General Power Tool Safety Warnings



#### WARNING

Read all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

Save all warnings and instructions for future reference.

#### 1. Work area safety

- a. Keep work area clean and well lit.
- b. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- c. Keep children and bystanders away while operating a power tool.

#### 2. Electrical safety

- a. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.
- b. Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges, and refrigerators.
- c. Do not expose power tools to rain or wet conditions.
- d. Do not abuse the cord. Never use the cord for carrying, pulling, or unplugging the power tool. Keep cord away from heat, oil, sharp edges, or moving parts.
- e. When operating a power tool outdoors, use an extension cord suitable for outdoor use.
- f. If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.

#### 3. Personal safety

- a. Stay alert, watch what you are doing, and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol, or medication.
- b. Use personal protective equipment. Always wear eye protection.
- c. Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.
- d. Remove any adjusting key or wrench before turning the power tool on.
- e. Do not overreach. Keep proper footing and balance at all times.
- f. Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing, and gloves away from moving parts.
- g. Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.

#### 4. Power tool use and care

- a. Do not force the power tool. Use the correct power tool for your application.
- b. Do not use the power tool if the switch does not turn it on and off.
- c. Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d. Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- e. Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- f. Use the power tool, accessories, and tool bits, etc., in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- g. Keep handles and grasping surfaces dry, clean, and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

#### 5. Service

- a. Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

#### 6. Equipment Installation, Operation, and Maintenance


- a. Safety of any system incorporating the equipment is the responsibility of the system assembler
- b. Position the equipment so that it is easy to access the disconnecting device
- c. Do not replace main power cord with an inadequately rated cord
- d. Only allow your power tool to be repaired by a qualified technician using only original spare parts, available from AIMCO. This ensures that the safety of your device is maintained.

#### 7. Air Handling

- a. In the event of loss of air flow to this unit, power must be turned off. Damage to air regulator can occur.
- b. Supply air that is filtered to 5 microns.


## 2. Controller Diagram

### 2.1 Bottom Panel iAC Basic Model




1	External Shutoff Valve Solenoid Connection 24 Volt terminal
2	Tool Connector
3	Power Disconnect Switch- Turns controller power on and off
4	Power Supply Cord Connection
5	System Port- USB-B connection used to connect external computer to configure/monitor the controller
6	Ethernet Ports RJ45 Connection used to connect external computer to configure/monitor the controller, or connect to plant wide network protocol infrastructure
7	USB-A Ports – Upload or download settings and logs. Controller upgrade.
8	Serial Port (DB-9Pin M) serial data output for communication with peripherals such as barcode readers
9	I/O Connector 24 Volt (DB-25 Pin M) input and output of signals for process control
10	Anybus-To connect customers field bus network ( Ex: Profibus)

### 2.2 Bottom Panel iAC Models with Shutoff Valve and/or Regulator



1	Air Outlet to the tool - 1/2" NPT (bottom exit versions)
2	Tool Connector (bottom exit versions)
3	Power Disconnect Switch- Turns controller power on and off
4	Power Supply Cord Connection
5	System Port- USB connection used to connect external computer to configure/monitor the controller
6	Ethernet Port RJ45 Connection used to connect external computer to configure/monitor the controller
7	Serial Port (DB-9Pin M) serial data output for communication with peripherals such as barcode readers
8	24 Volt I/O Connector (DB-25 Pin M) input and output of signals for process control
9	Anybus-To connect customers field bus network ( Ex: Profibus)
10	I/O Connector 24 Volt (DB-25 Pin M) input and output of signals for process control
11	Air Exhaust – 3/8" NPT

## 2.3 Top Panel iAC Models with Shutoff Valve and/or Regulator



1	Air Outlet to the tool – ½" NPT (top exit versions)
2	Tool Connector (top exit versions)
3	Air Supply Inlet to the tool 130 PSI maximum – ½"NPT
4	Air Exhaust – 3/8" NPT

## 2.4 Front Console LED Display

### Indicator Lights

Green	Indicates fastening cycle meets specified parameters.
Red	Indicates fastening cycle rejected for exceeding high torque.
Red Flashing	Indicates low torque. Fastening cycle was rejected for not achieving low torque.
Yellow	Indicates High Angle or High Pulse. Fastening cycle was rejected for exceeding high angle. Note: The angle indication overrides pulse in the case where the angle is high but the pulse is low.
Yellow Flashing	Indicates Low Angle or Low Pulse. Fastening cycle was rejected for not achieving low angle. The angle indication overrides pulse in the case where the angle was low but the pulse was high.
Blue	Tool is In-cycle, above threshold.



**Torque Display**  
Always displays torque value

**Secondary Display**  
Toggle button switches secondary display between

- Units of measure
- Ethernet IP address
- USB (System Port) IP address
- Angle report

NOTE: If Jobs are enabled refer to "4.3 Job" on page 18 for Toggle Button function.

**Toggle Button**  
Toggles what is shown in the secondary display

**Parameter Settings (PSet)/Job Display**

**Increment/Decrement Buttons**  
Change PSet or Job Number

## 3. Initial Setup

### 3.1 Air and Electrical Connections

**Step 1:** Connect the air components to the controller and tool. (See: typical installation configurations for the specific controller models below)

**Step 2:** Connect power cable to the # 5 power supply plug. (See "2.1 Bottom Panel iAC Basic Model" on page 4.)

**Step 3:** Connect sensor cable assembly to the IAC controller connection #2. (See "2.1 Bottom Panel iAC Basic Model" on page 4.)

**Step 4:** Connect the sensor cable to the URYU tool using the red mark to align pins correctly.

**Step 5:** Plug male end of power cable into appropriate power source


**Step 6:** Connect 24V external solenoid valve to 24 volt terminal on controller

**Step 7:** Connect power cable to the # 5 power supply plug. (See "2.1 Bottom Panel iAC Basic Model" on page 4.)


**Note:** Due to a variety of 230Vac power outlets, the standard power cable plug-end provided with the controller **may** need to be modified in order to connect to local 230Vac power outlets. AIMCO has a wide variety of country specific power cord options available. Check with your authorized AIMCO representatives to see if your specific configuration is available. In any case, connection to local power should be made in consultation with a qualified electrician.

**Step 8:** Turn controller on by pushing the Power Disconnect Switch #4 to the POWER ON position (see "2.1 Bottom Panel iAC Basic Model" on page 4). A light indicates power on.


#### Typical Air Connections for Base Models



#### Typical Air Connections for SR Models equipped with Internal Shutoff Valve and Digital Pressure Regulator



## Typical Air Connections for S Models equipped with Internal Shutoff Valve



## 3.2 Interfacing with the Controller

There are three ways to program/communicate with the controller:

- Controller touch-screen console
- System Port: (USB connection) Direct connection to controller.
- Ethernet Port: Via direct connection or LAN.

### Touchscreen Console

Controller functions and programming can be accessed directly through the touch-screen.

1. Power on controller.
2. Run screen will appear
3. Controller is ready for use.

### Connecting via the System Port Directly to PC


The following is an example using Window 7. Your screen may look different depending on the operating system.

### Windows USB Setup


**Step 1:** Power on PC and controller, allow enough time for them to become fully operational.

**Step 2:** Attach controller to PC using a USB 2.0 A-B cable. If this is the first time connecting the devices, wait for Windows to install the RNDIS driver. This should happen automatically.


**Step 3:** After the driver is installed, go to 'Control Panel'.




**Step 4:** Go to 'Network and Internet'.




**Step 5:** Go to 'Network and Sharing Center'.




**Step 6:** Go to 'Change adapter settings'.




**Step 7:** Find the Local Area Connection that is using the 'USB Ethernet/RNDIS Gadget' network. Right click this network and go to 'Properties'.



**Step 8:** In Properties window select 'Internet Protocol Version 4' and click 'Properties'.



**Step 9:** In 'Properties', set the IP address to a static address.



Type an IP address of 192.168.1.5 (Any address on the same subnet as the controller will work). Set subnet mask to 255.255.255.0

**Step 10:** To connect to the controller, open a browser such as Chrome or Firefox. Enter 192.168.1.4, the default system port IP address.





You will see the controller software on your computer screen.




## Connecting using the Ethernet Port Directly or via LAN to PC

Turn on the computer and make a physical connection by using a straight through Ethernet cable.


Turn on controller. Verify the controller IP address in 'Communication Interfaces' or press toggle button to verify the IP address. If defaulted 0.0.0.0 set desired IP address.

Set a static IP address of the Computer/Laptop to 10.10.30.98 (example) and subnet mask to 255.255.255.0. (For instructions, see the example in "Step 9" earlier in this section.)

To connect to the controller. In the Computer/Laptop open a browser such as Chrome or Firefox. Enter 10.10.30.99, the default Ethernet port IP address.



You will see on your computer screen the controller software



**NOTE:** Controller does not have a DHCP client, it will not automatically configure itself with a usable IP address. Consult your Network Administrator for configuring a correct IP address for your network. The PC, Laptop or Tablet IP address will need to be configured to communicate with the controller.

## 3.3 Enter Tool Information into the Controller

**Attention:** For proper operation of the tool, the tool ratings, calibration and other information must be entered into the tool setup screen.


This is done by navigating from the main menu to Controller → Tool Setup

## 3.4 Quick Set Up (Default PSets from Tool)


On the Home Page press the following to accept default PSet Parameters:



This will generate three generic PSets for the tool connected to the controller. It will automatically use the 40%, 60%, and 80% of the rated maximum torque of the tool in a two-stage Torque Control Strategy (TC\_PM). A prompt will display rated Max Torque and Max RPM of the connected tool for reference. These Psets can be modified to meet application requirements.




## 4. Home Page (Main Menu)




### 4.1 Run

The Run Screen is essentially the dashboard of the Gen IV controller and provides a look at real-time information regarding rundowns.



Time (In-Cycle) Screen

<b>JOB:</b>	Indicates the current JOB.
<b>PSet:01</b>	Indicates the current PSet in which you are operating.
	Indicates accepted rundown.
	Indicates failed rundown.
<b>8.56 Nm</b> <b>2785°</b>	Displays Torque and Angle for current rundown.
<b>21</b>	Number of Pulses.




Click on (or remote sessions can hover over) the rundown status icon or stop icons for a text description.

Graph displays curves representing Torque (black trace) and Angle (blue trace). The blue left arrow at the origin of the graph will change the X-axis of the rundown curve from Time (In-Cycle) to Time (Overall) and Angle.

Below the graph is a historical table that will give information and status of the most recent rundowns, including current PSet, accepted/failed rundown status, torque and angle.




Arrows allow user to scroll through screens that show real time Job information such as Run Screen or rundown indicators.



Home tab will return user to the Home Page

On the Run Screen, click for curve detail.




Click on blue arrow to change curve X axis.

Choose Time In-cycle, Time Overall, Angle, or Angle In-Cycle screen.


## Large Screen Indicators and Audit information

The large screen indicators are helpful in viewing real time results of the rundown from a distance.

Example of Accepted Job





Example of Failed Job








## 4.2 PSet

Parameter Settings (PSets) control the fastening process. The following describes the different fastening strategies and how to setup the basic PSet parameters necessary to perform a fastening. Up to 256 PSets are available.

### 4.2.1 Add New PSet


On Home Page press the  tab.  
On PSets screen press  to add a new PSet.



-  Add a PSet
-  Edit a PSet
-  Copy a PSet
-  Delete a PSet

**Default PSets:** See "3.4 Quick Set Up" on page 9.  
**Manage PSets:** See "4.2.6 Manage PSets" on page 17.

On Add New PSet screen (below) enter appropriate values.



**PSet Number:** Current PSet to be added.

**Torque Units:** Unit of measure.

**In Cycle Torque:** Threshold value at which tool is "In Cycle" and results from the Rundown will be reported. This value is also used to count pulses by determining the start of a pulse.


**Time Limit (s):** Maximum allowable time (in seconds) tool is allowed to run after going 'In Cycle'.

**Advanced Options:** (see "4.2.4 Advanced Options" on page 16)


Once PSet values are entered press  to enter **Add New Stage** screen.


#### 4.2.1.1 Add New Stage



A single stage or multiple stages build a PSet. Up to 20 stages can be assigned per PSet.



The following stage options are available (for stage descriptions, see "4.2.2 PSet Stages" on page 13):



Once the desired stage(s) are selected and configured, press  to save stage and again to save the **PSet** and return to initial PSet menu.

Next Press  to go to the **RUN** screen or  to return to the **Home** page. The tool should now be operational and you are ready to run a configured PSet.

## 4.2.2 PSet Stages

### 4.2.2.1 TC\_PM Torque Control Pulse Monitor

PSet 1: Edit Stage 1  
Stage Type

TC\_PM ▾

Torque

High

Target

Low

Pulse

Bailout

High

Low

Reference



Additional Pulses

Pressure

PSI

Time

Stage Timeout (s)

**Torque High:** Upper control limit of the rundown.

**Torque Target:** Final desired torque (CUT Level).

**Torque Low:** The lower control limit of the rundown.

**Pulse Bailout:** Total number of pulses never to be exceeded. Helps to illustrate how far past Pulse High the rundown experienced without damaging the part or excessively wearing the tool's pulse fluid.

**Pulse High:** Maximum acceptable pulses

**Pulse Low:** Minimum acceptable pulses

**Pulse Reference:** (drop down menu)

- **In-cycle Pulse:** Monitoring number of tool Pulse begins after the tool overcomes pre-set in-cycle Torque
- **Stage Pulse:** Monitoring all Pulses specifically in the Stage

**Additional Pulses:** After reaching target torque, additional pulses to be applied before shutting of the air to the tool.

**PSI:** Desired amount of air pressure supplied to the tool (Only available for SR models). Note: The pressure set in the first stage of the PSet, is applied when the tool is enabled to run.

**Stage Timeout (s):** Maximum allowable time (in seconds) in this stage. If time is exceeded, the tool will stop and the Rundown will be terminated.

## 4.2.2.2 TC\_APM Torque Control Angle Pulse Monitor

PSet 1: Edit Stage 1  
Stage Type

TC\_APM

Torque

High	45
Target	35
Low	25

Angle



Bailout	45
High	45
Low	25
Reference	In Cycle Ar
Reference Torque	0

Pulse

Bailout	100
High	100
Low	0
Reference	In Cycle Pl
Additional Pulses	1

Miscellaneous

Pressure (PSI)	65
Stage Timeout (s)	10

**Torque High:** Upper control limit of the rundown.

**Torque Target:** Final desired torque (CUT Level).

**Torque Low:** The lower control limit of the rundown.

**Angle Bailout:** Determines when to stop the tool on angle during any Torque Control strategy. Should be set equal to or above High Angle. Units are degrees of rotation.

**Angle High:** Maximum acceptable angle rotation in degrees.

**Angle Low:** Minimum acceptable angle rotation in degrees.

**Angle Reference** (drop down menu):

- **In-cycle Angle:** Monitoring degrees of Angle after the tool has overcome pre-set In Cycle Torque
- **Stage Angle:** Monitor Angle specifically in the Stage

**Angle Reference Torque:** Monitor degrees of Angle from the Reference Torque value set

**Pulse Bailout:** : Total number of Pulses never to be exceeded. Helps to illustrate how far past Pulse High the rundown experienced without damaging the part or excessively wearing the tool's Pulse Fluid

**Pulse High:** Maximum acceptable pulses

**Pulse Low:** Minimum acceptable pulses

**Pulse Reference** (drop down menu):

- **In-cycle Pulse:** Monitoring number of tool Pulse begins after the tool overcomes pre-set In Cycle Torque
- **Stage Pulse:** Monitoring all Pulses specifically in the Stage

**Additional Pulses:** After reaching target torque, additional pulses to be applied before shutting of the air to the tool.

**Pressure (PSI):** Desired amount of air pressure supplied to the tool (only available for SR models). Note: The pressure set in the first stage of the PSet, is applied when the tool is enabled to run.

**Stage Timeout (s):** Maximum allowable time(in seconds) in this stage. If time is exceeded, the tool will stop and the Rundown will be terminated.

## 4.2.2.3 TC\_AM Torque Control Angle Monitor

PSet 1: Edit Stage 1  
Stage Type

TC\_AM

Torque

High 45

Target 35

Low 25

Angle

Bailout 45

High 45

Low 25

Reference In Cycle Ar



Reference Torque 0

Pressure

PSI 65

Time

Stage Timeout (s) 10

**Torque High:** Upper control limit of the rundown.

**Torque Target:** Final desired torque (CUT Level).

**Torque Low:** The lower control limit of the rundown.

**Angle Bailout:** Determines when to stop the tool on angle during any Torque Control strategy. Should be set equal to or above High Angle. Units are degrees of rotation.

**Angle High:** Maximum acceptable angle rotation in degrees.

**Angle Low:** Minimum acceptable angle rotation in degrees.

**Angle Reference** (drop down menu):

- **In-cycle Angle:** Monitoring degrees of angle after the tool has overcome pre-set in-cycle torque
- **Stage Angle:** Monitor angle specifically in the stage

**Angle Reference Torque:** Monitor degrees of angle from the reference torque value set

**Additional Pulses:** After reaching target torque, additional pulses to be applied before shutting of the air to the tool.

**PSI:** Desired amount of air pressure supplied to the tool (Only available for SR models) Note: The pressure set in the first stage of the PSet, is applied when the tool is enabled to run.

**Stage Timeout (s):** Maximum allowable time (in seconds) in this stage. If time is exceeded, the tool will stop and the Rundown will be terminated.

## 4.2.2.4 AC\_TM Angle Control Torque Monitor

PSet 1: Edit Stage 1  
Stage Type

AC\_TM

Angle

High 45

Target 35

Low 25

Reference In Cycle Ar

Reference Torque 0

Torque

Bailout 67.5

High 45



Low 25

Pressure

PSI 65

Time

Stage Timeout (s) 10

**Torque High:** Upper control limit of the rundown.

**Torque Target:** Final desired torque (CUT Level).

**Torque Low:** The lower control limit of the rundown.

**Torque Reference** (drop down menu):

- **In-cycle Angle:** Monitoring degrees of angle after the tool has overcome pre-set in-cycle torque
- **Stage Angle:** Monitor angle specifically in the stage

**Reference Torque:** Monitor degrees of angle from the reference torque value set

**Torque Bailout:** Total amount of torque not to be exceeded. Helps to illustrate how far past Torque High the rundown experienced without damaging the part.

**Torque High:** Maximum acceptable pulses



**Torque Low:** Minimum acceptable pulses

**PSI:** Desired amount of air pressure supplied to the tool (Only available for SR models). Note: The pressure set in the first stage of the PSet, is applied when the tool is enabled to run.

**Stage Timeout (s):** Maximum allowable time (in seconds) in this stage. If time is exceeded, the tool will stop and the Rundown will be terminated.


## 4.2.3 Edit PSet

On Home page press




On the PSet screen click on the desired PSet you would like to edit.

Click on the Edit button to make changes in the Edit screen (below).




If further Stage changes are needed click the Edit button again to enter Edit Stage screen (below).



Once desired changes are made click twice to save changes.

## 4.2.4 Advanced Options



**PSet Name:**  
(optional)

**Thread Direction:**  
Direction the tool is required to run for fastening.  
**NOTE:** The actual tool direction is set on the tool.

**Judgement Delay:**  
Delay after the air is shutoff to the tool, where the peak torque, pulse count, and angle are still being recorded. After this delay the rundown is evaluated and reported as

complete. This timer starts when the final stage of the PSet is complete.

**Torque Read Delay:** The primary use of this timer is to ignore seating torque or early stray pulses from contributing to the rundown results. This timer starts



when the torque reaches In-Cycle. During this delay time, torque is not compared to the target. When the time is up, the peak torque is reset. This can be useful if there is an initial spike in the torque when the tool first starts or at the fasteners first seating point.

**Pulse Timeout:** The primary use for this timer is to detect trigger release. This timer starts after a pulse is detected. If another pulse is not detected before the timer expires then the rundown will terminate

**Re-hit/Reject Parameters:** Prevents the fastening of an already tightened fastener. If enabled, tool will stop and the rundown will be aborted, if the angle of rotation between the Re-Hit Reference Torque and the In-Cycle Torque is less than the Re-Hit Angle Count.

**NOTE:** If the attempted rundown is a Re-Hit, it will not be reported or recorded.

**Re-hit Reject Enable:** Enables the feature.

**Report Re-Hit as NOK:** If checked the results of the rundown will be NOK with torque, angle and pulse reported as LOW.

If not checked, the tool will be shut off and the controller will not go into cycle.

**Re-Hit Angle Count:** The default Re-Hit Angle Count is 100 degrees. If the angle changes less than 100 degrees in .04 seconds before the in-cycle pulse it is determined to be a Re-Hit.

**Joint Compensation Ratio:** Adjusts the target torque of the tool to compensate for joint characteristics. This value has an inverse relationship with the target torque (Output torque = Target Torque / Ratio). Ratio values above 1.0 result in a lower output torque where values below 1.0 result in higher output torques.

**Pulse Detection Thickness Threshold:** This adjusts the pulse thickness threshold for determining if a pulse has occurred. The default is 6. In most cases this default is the optimal setting. However, in some applications, where the pulses produced by the tool are very thin, the default setting does not detect all the significant pulses and in some cases will cause a Pulse Timeout to occur. If this is happening, try lowering the Thickness Threshold to a value that allows the capture of all the meaningful pulses.

---

## 4.2.5 Default Psets


---

See "3.4 Quick Set Up" on page 9.

---

## 4.2.6 Manage PSets

---



### Save PSets to Browser

Allows the PSet information to be saved to the local PC connected to controller. PSet information is saved as a .txt file and can be opened using any text editor such as WordPad. It can also be opened with Excel. The format of the .txt file is tab separated values.

### Export PSets to Browser

Save the PSets as a database file to the PC connected to controller. These PSets can later be imported to another controller.

### Import PSets from Browser

Import previously exported PSets to controller.

### Delete PSets


Enables deletion of selected PSets.

## 4.2.7 Multistage Rundown Evaluation and Reporting

- If a rundown cycle completes, or is terminated early while in or after the final stage of the PSet:
  - The overall evaluation of the rundown will be determined using the limits set in the final stage.
  - The peak torque, pulse count, and angle, achieved during the rundown, are used for the evaluation and reported.
  - Note: The fastening torque must reach the In-Cycle torque value set in the PSet in order for the rundown to be evaluated and reported.
  
- If a rundown is terminated early before reaching the final audit stage:
  - The overall result of the rundown will be reported as a reject.
  - The torque, pulse, and angle evaluation will be determined using the limits set in the stage that was running when the rundown was terminated.
  - The peak torque, pulse count, and angle at the point in time when the rundown was terminated, is used for the stage evaluation.
  - The torque, pulse count, and angle status reported will reflect this stage evaluation with the following exception:
    - If torque, pulse count, and angle are all within limits of the stage that was running, the torque, pulse, and angle status will all be reported as low. This is done to further indicate that the rundown terminated before reaching the final audit stage.
  - The peak torque, pulse count, and angle achieved, during the rundown, will be reported.
  
- Angle measurement details:
  - Peak Angle used for overall evaluation and reported is the peak angle achieved during the rundown, measured from the angle reference set in the final stage. Note: If an angle reference is not defined in the final audit stage, the angle is measured from when the torque first crosses the In-Cycle torque set in the PSet.
  - Angle used for stage evaluation is the angle at the point in time when stage was terminated or completed, measured from the angle reference set in the stage.
  
- Note: If the evaluation of any stage during the rundown fails, or a bail out limit is exceeded, the fastening cycle will be terminated early and any subsequent stages will not run.

## 4.3 Job

A Job is a collection of PSets which can be run when performing multiple fastening operations on a single application.





Jobs provide:

- Error proofing
- Logical grouping of PSets
- Fastening order
- Job status

Click to Enable/Disable Job function.

### 4.3.1 Add New Job

To add a new Job press  on the Home Page. Press  on Jobs screen (above) to enter Add New Job screen (below)

**Job Number:** Up to 99 Jobs can be configured.

**Job Name:** Enter Job Name

**Job Action:**

- **Disable Tool:** Disable tool after job is finished. Job complete icon will appear.



Tool will not operate until job is reset.


- **Reset Job:** Will reset after Job is finished. Once Reset Job is finished, the following icon appears:




This means that results from the last successful rundown of a job are cleared. Information from last successful rundown can still be accessed in the table of the rundown view/curve display on the main Run Screen (see "4.1 Run" on page 10.

The screenshot shows the 'Add New Job' screen. It has three input fields: 'Job Number' with a dropdown menu showing 'Job 1', 'Job Name' with a text input field, and 'Job Action' with a dropdown menu showing 'Disable Tool'. Below these fields is an 'Advanced Options' section with a table. The table has columns for 'PSet' and 'Action'. At the bottom of the screen is a toolbar with icons for adding, editing, deleting, and enabling/disabling jobs, along with a green checkmark and a red prohibition sign.

Enter Advanced Options Advanced Options if needed (see next section "4.2.4 Advanced Options")

After appropriate values are entered, press  to go to Add New Job Sequence screen.



**PSet Number:** Choose any current PSet already configured in controller.


**Action:**

- **None:** Will stay in current sequence.
- **Next:** will advance to next sequence set up after count is reached.

**Count:** Fastener number required to complete sequence.


Once values are entered press  two times to return to Job screen

### 4.3.2 Advanced Options



**Lock on Reject Parameters:**

- **Enable:** When enabled, this prevents tool from starting a new rundown if the result of the last rundown was a reject. The tool can be enabled with the "Remove Lock on Reject" assignable input.



**Limit Reject Parameters:**

- **Enable:** Enable or Disable
- **Maximum Rejects:** Number of rejected fasteners allowed

**Additional Options:**

- **Report Missing Fasteners:** Add an option to each JOB to allow the reporting of any missing

fasteners. When it is set, the controller will report an NOK rundown for each fastener that is defined in the JOB but has not been run. These NOK results will be reported whenever a new job is started AND the prior JOB is incomplete.

These generated NOK results are treated like any other fastening. They are displayed on the run screen, stored in the results and transmitted on all protocols.

### 4.3.3 Jobs "Enabled" Display and Button Function



- Increment and Decrement buttons change the job sequence. The PSet number will change and job sequence number on **secondary display** will change if jobs are enabled.
- Holding the toggle button will display will display the Job number, while pressing increment or decrement buttons will change it. The two numbers on the PSet/Job display will be separated by decimals.
- Pressing the toggle button will change **secondary display** between:
  - Units of measure
  - Ethernet IP address
  - System port IP address
  - Angle report (If tool is equipped with angle resolver)
  - Bolt count
  - Job sequence

**NOTE:** Job sequence shows which PSet you are currently on in the job (this is not the pset number). The first pset in the job is always job sequence 1, and the next is 2, etc.

Bolt count is shown as current bolt count out of total number of bolts. Example: If you have 3 total bolts. When you start the job you will see 0.3. After one rundown you will see 1.3 and then 2.3 on the next run and so on until the job is completed.


## 4.4 Results

ID	Time Stamp	PSet	OK	Torque	Angle	Fault
72	08/04 00:26:44	5	✓	1.25 Nm	124°	
71	08/04 00:26:44	5	✓	1.09 Nm	14.0°	
70	08/04 00:26:43	5	✓	1.15 Nm	22.7°	
69	08/04 00:26:42	5	✓	1.28 Nm	22.2°	
68	08/04 00:26:41	5	✓	1.26 Nm	207°	
67	08/04 00:26:39	4	✓	15.49 Nm	221°	
66	08/04 00:26:37	4	✓	15.26 Nm	218°	
65	08/04 00:26:34	4	✓	16.33 Nm	2.4°	
64	08/04 00:26:31	5	✓	1.53 Nm	22.7°	
63	08/04 00:26:30	5	✓	1.60 Nm	32.3°	
62	08/04 00:26:30	5	✓	1.51 Nm	19.3°	
61	08/04 00:26:29	5	✓	1.13 Nm	242°	
60	08/04 00:26:28	5	✓	1.13 Nm	250°	

This screen provides a history of rundowns performed. Information such as ID Number, Time Stamp, Parameter Set#, Accept/Reject status, and Torque and Angle are recorded for each rundown.

ID	Time Stamp	PS...	OK	Torque	Angle
112	01-01 02:29:00	1	✓	12.03 Nm	124
111	01-01 02:28:56	1	✓	11.98 Nm	124
110	01-01 02:28:50	1	✓	12.02 Nm	112
109	01-01 02:28:46	1	✓	11.63 Nm	113
108	01-01 02:20:13	1	✗	2.56 Nm	34


Click on Individual Runs for Rundown information.




Example: Rejected Rundown Information.

### 4.4.1 Saving Rundown(s)

#### Saving All Rundowns








Click on  in main rundown screen to view/save total rundowns. A dialog box will open that allows you to choose the download format, either a CSV file or a TW4 file. The CSV file includes rundown data in tab separated variables and can be viewed using Excel or opened in text editor such as Notepad. The raw data can be imported to Excel to build graphs, charts etc. Contact AIMCO Technical Service for pre-made Torque and Angle Templates.

The TW4 file can be opened using the ACE Platform G4 Utility located on the [software page](#) of the AIMCO website.



The dialog box also shows options for including stage results or log entries in the downloaded file. If downloading a TW4 file, all information will be automatically selected.

Click  and your browser will download the file.

	Filter Button gives filter options in Rundown screen.
	Save Button saves rundowns as .Txt File.
	Deletes individual rundowns by clicking on them
	Select Columns Button lets you customize the columns shown on the Results Screen
	Home Button returns to main display menu.
	Play Button sends you directly to Run Screen.
	Refresh Button refreshes screen to include latest rundowns.


Select Columns	
Rundown ID	<input checked="" type="checkbox"/>
Timestamp	<input checked="" type="checkbox"/>
PSet	<input checked="" type="checkbox"/>
OK/NOK	<input checked="" type="checkbox"/>
Torque	<input checked="" type="checkbox"/>
Angle	<input checked="" type="checkbox"/>
Pulses	<input type="checkbox"/>
Barcode ID #1	<input type="checkbox"/>
Barcode ID #2	<input type="checkbox"/>
Barcode ID #3	<input type="checkbox"/>
Barcode ID #4	<input type="checkbox"/>
Stopped	<input type="checkbox"/>
Aborted	<input type="checkbox"/>
Faulted	<input checked="" type="checkbox"/>

## Saving Individual Rundowns


ID	Time Stamp	PS...	OK	Torque	Angle
490	01-01 01:01:28	1	✓	15.69 Nm	3
489	01-01 01:01:27	1	✓	15.33 Nm	3

To save an individual rundown, select a

rundown from the Results screen.

This opens the Rundown Information View. Click on  in save the rundown. The file will automatically download as a CSV file.

Rundown Information View



Sample of Individual Rundown Information

1	Result	65	
2	Job Numb	1	
3	Job Name	Paramont	
4	Job Sequ	1	
5	Bolt Coun	3	
6	Date	##### 4:18:00	
7	Master Ru	0	
8	PSet ID	59	
9	PSet Num	1	
10	PSet Name		
11	Tool Mod	AEN32030A	
12	Tool Seria	191111	
13	Torque	11.69	
14	Angle	57	
15	Pulses	0	
16	Torque St: P		
17	Angle Stat --		
18	Pulse Stat --		
19	Rundown P		
20	Tool Cycle	1111	
21	ID1 ("ID #1)	2.2E+10	
22	ID2 ("ID #2)	4.86E+10	
23	ID3 ("ID #3")		
24	ID4 ("ID #4")		
25			
26			
27			
28	Curves		
29	Tick	Torque	Angle
30	0	0.02	0
31	1	0.02	0
32	2	0.05	0
33	3	0.04	0
34	4	0.09	0

The format can also be changed with the optional "version" parameter. An http request to the controller for file "fastening.csv" with the optional parameter "version" set to 1 (<http://ipaddress/fastening.csv?version=1>) will return a CSV file in the "QualityWorX File" format.


The "id" and "version" options can be used in any combination as needed.

## HTTP Method for Retrieving and Saving Rundown Results

An http request to the controller for file "fastening.csv" (<http://ipaddress/fastening.csv>) will return the most recent rundown in the full rundown CSV format. This is in the same format as "Home->Results" selecting a results then selecting save.


Optionally, a specific ID can be selected. An http request to the controller for file "fastening.csv" with the optional parameter "id" set to the desired id number (<http://ipaddress/fastening.csv?id=47>) will return rundown id the full rundown CSV format.

## 4.5 Controller



The controller menu is where all of the settings for the Gen IV controller are configured. All of the different configuration capabilities are explained below.

### 4.5.1 Tool Setup



In this screen user can enable/disable various tool functions.

#### 4.5.1.1 Tool Parameters

For proper operation of the tool, this information must be entered each time a new tool is connected to the controller.

**Tool CAL:** Value stamped on tool.

**CAL Ratio:** Calibration factor for matching the torque reading of the tool/controller to a torque auditor.

**Maximum Torque (Nm):** Rated maximum torque of the tool. This is used when determining the default PSets.


**Rated Speed:** Rated catalog speed of the tool. (Optional information only. Does not affect the operation of the tool)

**Model Number:** (Optional information only. Does not affect the operation of the tool)

**Serial Number:** (Optional information only. Does not affect the operation of the tool)

**Valve Return Delay:** Time from when the air to the tool shuts off after a rundown, to when the tool air turns back on for the next rundown.

**Angle Resolver:** Tool is equipped with an angle sensor 'Resolver'.



## 4.5.1.2 Disassembly

**Report Disassembly:** If enabled, disassembly events will be reported and logged.

**Threshold Torque:** Disassembly will be reported only if this torque value is reached. This is entered as a positive value.

**Torque Units:** Units for the Disassembly Threshold Torque

**Decrement Fastener Count:** If Disassembly is detected the fastener count in JOBS

- **Never:** Decrement count will be ignored
- **Always:** Decrement will always be active
- **Only after NOK:** Decrement count will only happen after a rundown judged to be NOK (Reject) has occurred

**Disable on Disassembly:** If disassembly is detected the tool will be disabled

**Judgment Delay (s):** Amount of time between signal from transducer and when value is applied against limits. In a Pulsing tool this takes into account rebounding after final

**Pressure:** Desired air pressure delivered to the tool for use in disassembly (only usable when controller is an SR model)

### When a disassembly event is reported:

The disassembly will be displayed on the run screens and logged in the rundown record, containing the following:

- Overall evaluation will be marked as 'Disassembled' Peak torque during the disassembly (torque shown as negative).
- Peak overall angle during the disassembly (angle shown as negative).
- Curve data from the disassembly
- Parameters from the current PSet selected
- Fastening events from the disassembly.

All of the controller's status LEDs will be turned OFF. The LED display will show peak torque and angle as negative

### I/O Considerations:


When disassembling, all assignable IO outputs that report rundown status will remain in the state from the last fastening cycle. This includes:

- Ok and Nok signals
- Torque/Angle high or low signals
- Torque and Angle Values

All assignable I/O outputs reporting a fastening events will not change state during the disassembly. This includes:


- Fastening Complete
- In Cycle
- Fastening Stopped
- Fastening Aborted

**NOTE:** When the tool is placed into disassembly mode, all of the tool's LEDs flash and the Horn beeps. This will continue until the tool is placed back into fastening mode.




## 4.5.1.3 Lock Tool On Reject

When enabled, this prevents tool from starting a new rundown if the result of the last rundown was a reject. The tool can be enabled with the "Remove Lock on Reject" assignable input.



## 4.5.2 IO



### 4.5.2.1 Physical IO

Physical IO Configuration			
Input	Function	State	Force
---1---		<input type="checkbox"/>	<input type="checkbox"/>
---2---		<input type="checkbox"/>	<input type="checkbox"/>
---3---	Stop	<input type="checkbox"/>	<input type="checkbox"/>
---4---	Select PSet / [...	<input type="checkbox"/>	<input type="checkbox"/>
---5---	Used By Input:...	<input type="checkbox"/>	<input type="checkbox"/>
---6---	Used By Input:...	<input type="checkbox"/>	<input type="checkbox"/>
---7---	Reset Job	<input type="checkbox"/>	<input type="checkbox"/>
---8---		<input type="checkbox"/>	<input type="checkbox"/>

Output	Function	State	Force
---1---	OK	<input type="checkbox"/>	<input type="checkbox"/>
---2---	NOK	<input type="checkbox"/>	<input type="checkbox"/>
---3---	In Cycle	<input type="checkbox"/>	<input type="checkbox"/>
---4---	Torque High	<input type="checkbox"/>	<input type="checkbox"/>
---5---	Torque Low	<input type="checkbox"/>	<input type="checkbox"/>
---6---	Angle High	<input type="checkbox"/>	<input type="checkbox"/>
---7---	Angle Low	<input type="checkbox"/>	<input type="checkbox"/>
---8---	Job Complete	<input type="checkbox"/>	<input type="checkbox"/>

Assign functionality to 24V Input and Output pins. Shows the "live state" of each Input and Output.

Functions shown in screen shot are default settings.


To change these assignments, click on the "Function" column of any of the I/O

pins. This will open a Output/Input Configuration screen (following).


Click on the "Force" column of any of the I/O pins to enable or disable the forcing of the selected input or output.

If force is enabled, click on the "State" column to toggle the state of input or output selected.

### Input Configuration



### Output Configuration



See "11. Assignable I/O" on page 48 for more details on available assignment functions and how to configure.

See "10. 24 Volt I/O" on page 46 for the pinout of the 24Volt Logic IO port, and wiring examples.

### 4.5.2.2 Physical IO Monitor


Provides monitoring of Physical 24 Volt I/O. Force on/off the individual I/O pins for testing of field wiring.

Each indicator shows the state of the associated pin.

Green = On  
Red = Off

- Force:** When Buttons from I/O are selected, this field selects which Inputs and Outputs can be forced through the Monitor I/O screen.


- Off/On:** If Force is enabled this button will toggle the state of input or output selected.






## 4.5.2.3 Anybus/Modbus TCP/Ethernet IP Inputs

These types of communication are useful for data communication between controller and PLCs. It is an effective, quick way for the data transfer of short data packages.



Press  to enter Input Configuration Screen



**Element Type:** Choose from Byte, Int16, Int32, or ASCII.

**Element:** Shows element # being configured

**Bit** (not shown): Enter Bit #.

**Bits:** # of bits the assignment will read.

**Start at:** Starting bit location.

**Polarity** (not shown): Select Normally Open (N.O.) or Normally Closed Outputs (N.C.).

**Length** (not shown, available in ASCII ID function): Number of characters desired to send.


**Torque** (not shown, available in Click Wrench function): Torque value to be reported when using Click Wrench input. Value input is what will be sent from controller when Input Signal is received from a Click Wrench. **Value is NOT calculated by the controller rather it is solely what the Click Wrench is calibrated to by outside means.**


**Torque Units** (not shown, available with Click Wrench function): Choose from Nm, Kgm, Kgcm, Ftlb, and Inlb.

**Function:** See "11. Assignable I/O" on page 48 for more details on assignable functions.

Click on  after appropriate selections are made.

Example of the Anybus Input screen with five Inputs set up.





Click on  to change an individual Element or return to Input Configuration screen.




Will delete individual Elements.

## 4.5.2.4 Anybus/Modbus TCP/Ethernet IP Outputs



Press  to enter Output Configuration Screen



**Element Type:** Choose from Byte, Int16, or Int32.

**Element:** Shows Element # being configured.

**Bit:** Enter Bit #


**Bits** (not shown): # of bits the assignment will read.

**Start at** (not shown): Starting bit location.


**Polarity:** Select Normally Open (N.O.) or Normally Closed (N.C.) Outputs.

- Mode:**
- **Normal:** Output signal sent.
  - **Timed Signal Sent:** Time entered in seconds
  - **Flash Signal Sent:** Time entered in seconds


**Function:** See "11. Assignable I/O" on page 48 for more details on assignable functions.

Click on  after appropriate changes are made.


Example of the Anybus Output screen with five Outputs set up.




Click on  to change an individual Element or return to Input Configuration screen.

 Will delete individual Elements.

## 4.5.3 Communication Interfaces



### 4.5.3.1 Ethernet/Second Ethernet




**IP Address:** IP address of controller's Ethernet port.

**Subnet Mask:** Subnet mask of the controller.

**Gateway:** Gateway is the IP address of the gateway computer that provides access beyond the local network.

**NOTE:** Consult your local System Administrator to connect the controller to your Network and assign IP addresses.

### 4.5.3.2 System Port



**IP Address:** The IP address of controller's System Port (Default is 192.168.1.4)


**Subnet Mask:** The Subnet Mask of controller's System Port.

**NOTE:** It is not recommended to change this setting.

### 4.5.3.3 Serial Port

**Port Mode:** The following modes are available:

- **PI Line Control:** This is customer specific. Please reference PI Line Control Document on [AIMCO Website/Manuals](#).
- **Serial Output:** A serial data string will be Output after each rundown
- **Barcode Reader:** See "5. Barcode Reader Details" on page 40 for Barcode setup.
- **Serial Output and Barcode Reader:** Select from dropdown and configure per hardware requirements



- **Open Protocol:** Select from dropdown and configure per hardware requirements
- **PFCS:** Select from dropdown and configure per hardware requirements
- **PI Line Control:** This is customer specific. Please reference PI Line Control Document on [AIMCO Website/Manuals](#).
- **Tohnichi Wrench:** Supports connecting a Tohnichi wrench/R-CM receiver to the controller. See Gen IV Serial Instructions on [AIMCO Website/Manuals](#).

**Baud:** Serial ports can be configured for different baud rates available.

- 75, 110, 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200

**Data Bits / Stop Bits / Parity:** Configure per hardware requirements

**Serial Output Formats:** See "Serial Output Format Options" on page 29 for details.

- Standard
- Standard with PSet
- UEC Serial Modified
- Profibus
- UEC Serial
- CVS String

**Output Followed by Null Control Character:** Adds a one-byte NULL character to the end of the serial string. Needed by systems that use the NULL character to signify the end of the string. See following section for more information.

#### Send PSet Change


- Sends a serial string any time the PSet is changed. String is in the form '%CAN8X%%CAN4YNAC%%' where X is the previous pset and Y is the new pset. See following section for more information.

#### Send Job Completed:


- Sends a serial string containing "Job Completed" whenever a job has been completed.

#### Gen IV Serial Port Pin-out

Pin	Signal
1	
2	RX
3	TX
4	DTR
5	GND
6	
7	
8	
9	




#### 4.5.3.4 Anybus




**Node Address:** Configures the Anybus node address for controller.

#### 4.5.3.5 Spindle USB Port



This can be used to set up a 2 spindle network through the USB port.

#### 4.5.3.6 Serial USB



See "4.5.3.3 Serial" on page 27 for reference

## Serial Output Format Options

### Standard Output Format:

- O P HHHHH LLLLL TTTT P HHHHH LLLLL AAAAA CR CR NULL\*
  - O: Overall Pass/Fail
    - 'P' = Pass, 'F' = Fail
  - P: Torque Pass/Fail
    - 'P' = Pass, 'F' = Fail
  - HHHHH: Torque High Limit
    - Units selected in the PSet X10
  - LLLLL: Torque Low Limit
    - Units selected in the PSet X10
  - TTTT: Torque Result
    - Units selected in the PSet X10
  - P: Angle Pass/Fail
    - 'P' = Pass, 'F' = Fail
  - HHHHH: Angle High Limit
    - Degrees
  - LLLLL: Angle Low Limit
    - Degrees
  - AAAAA: Angle Result
    - Degrees
  - CR: Carriage return control character
  - CR: Carriage return control character
  - NULL\*: Null control character (\*if option is selected)

### Standard Output with Carriage Return, Line Feed and PSet Format:

- O P HHHHH LLLLL TTTT P HHHHH LLLLL AAAAA 1 CR LF NULL\*
  - O: Overall Pass/Fail
    - 'P' = Pass, 'F' = Fail
  - P: Torque Pass/Fail
    - 'P' = Pass, 'F' = Fail
  - HHHHH: Torque High Limit
    - Units selected in the PSet X10
  - LLLLL: Torque Low Limit
    - Units selected in the PSet X10
  - TTTT: Torque Result
    - Units selected in the PSet X10
  - P: Angle Pass/Fail
    - 'P' = Pass, 'F' = Fail
  - HHHHH: Angle High Limit
    - Degrees
  - LLLLL: Angle Low Limit
    - Degrees
  - AAAAA: Angle Result
    - Degrees
  - 1: PSet
    - PSet('1' - '9') for PSets 1-9, ('A' - 'Z') for PSets 10-35
  - CR: Carriage return control character
  - LF: Line feed control character
  - NULL\*: Null control character (\*if option is selected)

### UEC Serial Modified Format (matches some Gen4 earlier versions):

- # P 1 BB TTT.T AAAA PPPP 0000 J CR NULL\*
  - #: Message Start
  - P: PSet
    - PSet('1' - '9') for PSets 1-9, ('A' - 'Z') for PSets 10-35
  - 1: Spindle Number (Always 1)
  - BB: Job Bolt Count
    - Total number of accepts during the Job
  - TTT.T: Torque Result
    - Units selected in the PSet
  - AAAA: Angle Result
    - Degrees
  - PPPP: Pulse Count
  - 0000
  - J: Judgment
    - '@' = Overall Pass, 'H' = Low Torque, 'I' = High Torque, 'J' = Low Angle, 'K' = High Angle, 'G' = Fault During Fastening
  - CR: Carriage return control character
  - NULL\*: Null control character (\*if option is selected)

### Profibus Output Format:

- %CAN 1 O P HHHHH LLLLL TTTT P HHHHH LLLLL AAAAA NAC% CR LF NULL\*
  - %CAN: Message Start
  - 1: PSet
    - PSet('1' - '9') for PSets 1-9, ('A' - 'Z') for PSets 10-35

- O: Overall Pass/Fail
  - 'P' = Pass, 'F' = Fail
- P: Torque Pass/Fail
  - 'P' = Pass, 'F' = Fail
- HHHHH: Torque High Limit
  - Units selected in the PSet X10
- LLLLL: Torque Low Limit
  - Units selected in the PSet X10
- TTTT: Torque Result
  - Units selected in the PSet X10
- P: Angle Pass/Fail
  - 'P' = Pass, 'F' = Fail
- HHHHH: Angle High Limit
  - Degrees
- LLLLL: Angle Low Limit
  - Degrees
- AAAAA: Angle Result
  - Degrees
- NAC%: Message End
- CR: Carriage return control character
- LF: Line feed control character
- NULL\*: Null control character (\*if option is selected)

### UEC Serial Format (matches UEC 4800 and Gen3):

- # 1 P BB TTT.T AAAA PPPP 0000 J CR NULL\*
  - #: Message Start
  - 1: Spindle Number (Always 1)
  - P: PSet
    - PSet('1' - '9') for PSets 1-9, ('A' - 'Z') for PSets 10-35
  - BB: Job Bolt Count
    - Total number of accepts during the Job
  - TTT.T: Torque Result
    - Units selected in the PSet
  - AAAA: Angle Result
    - Degrees
  - PPPP: Pulse Count
    - L = Low Pulse Count, M = High Pulse Count
  - 0000
  - J: Judgment
    - '@' = Overall Pass, 'H' = Low Torque, 'I' = High Torque, 'J' = Low Angle, 'K' = High Angle, 'G' = Fault During Fastening, '\*' = None of these conditions apply
  - CR: Carriage return control character
  - NULL\*: Null control character (\*if option is selected)

### 'CSV String'

S01,JB01,TTT.T,S,AAA.A,S,O,MM/DD/YYYY HH:MM:SS,VVV<CR><LF>

S01: Spindle number

JB01: Job number

TTT.T: Torque

S: Torque Status (A = OK, H = High, L = Low)

AAA.A: Angle

S: Angle Status (A = OK, H = High, L = Low)

O: Overall Status (A = OK, R = NOK)

MM: Month

DD: Day

YYYY: Year

HH: Hour

MM: Minute

SS: Second

VVV: 32 character barcode ID

<CR>: Carriage Return

<LF>: Line Feed

### 'Output Followed by NULL Character'

The NULL characters can be seen by using PUTTY and connecting to the controller in 'Raw' mode. Then set logging to log all output and check the log to see the NULL characters.

### 'Send PSet Change'


PSets up to 9 match the number, 10-35 are A-Z, greater than 35 is '\*':

%%CAN8X%%%%CAN4YNAC%%

X: Last PSet


Y: New PSet

## 4.5.4 Protocols



For information about these settings, see individual protocol instructions on AIMCO's website at [www.aimco-global.com/manuals](http://www.aimco-global.com/manuals).


## 4.5.5 Front Panel Buttons



Enable/ Disable front panel buttons on controller console.

## 4.5.6 Power Up

Allows user several "Job" choices upon controller Power Up:



### Power Up Job

**Number:** Controller will power up on the job # selected.

- **Last Job:** When "Last job" is selected, controller will power up on last job selected prior to being Powered Down.

### Power Up Job Action


- **Reset Job:** Job will be reset when controller is Powered Up.
- **Wait for Job Reset:** Controller will wait for an External Job reset command upon Power Up and will retain job information existing prior to power down.
- **Resume Last Job:** Upon Power Up, tightening sequence will resume at the next fastening from the point in the job when power was shut down.

## 4.5.7 Bar Code Setup

**Required Identifiers for Tool Enable:** Selects which four Identifiers (ID#1-4) are required to enable tool.


**Reset identifiers for Job Complete:** Selects which four Identifiers (ID#1-4) to reset on a job complete. Select Identifiers by clicking on them.

**Block New Identifiers While Job is Running:** Check to enable feature that ignores any barcode scanning while a JOB is in progress



**Step 2:** Enter appropriate information on Barcode ID Configuration Screen.

**Identifier Mask:** The Mask is a string used to compare the received barcode against. The received barcode must be at least as long in length as the Mask. The Mask can also contain "don't care" characters of a decimal point or period in the string. These characters are counted in the length, however, the actual received character in that position doesn't matter.



Example:



VIN#123456

**Identifier Type:** Identifies which identifier (ID# 1-4) received barcode will be stored into.


**Identifier Description:** Text field can be used to give a description to each identifier type. (Example: Vehicle).


**Action:** Action executed by controller when barcode with a matching identifier mask is scanned. The actions are:

- Select Job ( This will require a Job to be configured on the JOB page when using this option)
- Do Nothing
- Select PSet

**Action#:** When Select Job or Select PSet is selected, this is the number of the Job or PSet that will be selected.

**Reset Identifiers:** Can reset other identifiers (ID# 1-4) when barcode is received. Click on identifiers to reset.

**Step 3:** Press  to save and re-enter completed barcode configuration screen.




Click anywhere in body if additional identifiers are required.

Press  to save barcode configuration.

See "5. Barcode Reader Details" on page 40 for more information)


To configure Serial Port for Barcode Reader:  
On Home page click Controller → Communication Interfaces → Serial

Select Barcode Reader and the correct Baud rate.




Press  to save changes.

## 4.5.8 Set Time



Set time and date. If connected to a PC, use PC Time to set controller time.

## 4.5.9 Remote Connections




Sets number of remote browser connections to controller.

Displays the IP addresses of remote browser connections to the controller.

## 4.5.10 Lock Tool on Reject


When enabled, the tool will be disabled after an NOK rundown. The tool can be enabled with the "Remove Lock on Reject" assignable input.




## 4.5.11 Languages

Select from:

- English
- Chinese
- Japanese
- Korean
- Spanish
- Portuguese




## 4.6 Accessories



This screen shows accessories configured in the controller. New accessories can be added, edited, and deleted using the buttons at the bottom of the table. The gear icon navigates to the Accessory Scanning and Setup page.

## 4.7 Diagnostics



The Diagnostics menu contains all pertinent information regarding unusual behavior of the system. Detailed descriptions are given in the following sections.

### 4.7.1 Controller Overview

**Model Number:** Model Number of the controller.

**Serial Number:** Serial Number of the controller.


**Type:** Type of controller:  
**IAC4:** Intelligent Air Controller

**SYSREL:** System Release # shown

**Application:** Current Application software version.

**Firmware:** Current Firmware software version.

**Available Hardware:** Hardware configuration of the controller





## 4.7.2 Controller Status

Controller Status	
<b>Bus Voltages</b>	
24 Vdc	OK
15 Vdc	14.94
-15 Vdc	-15.06
5 Vdc	4.92
3.3 Vdc	3.27
SOM 1.8 Vdc	1.82
Mainboard 1.8 Vdc	1.80
Torque Vdc	0.01
<b>Temperatures</b>	
CPU Temperature (° C)	35
Mainboard Temperature (° C)	40
<b>Active Faults</b>	

Shows "Live" status of controller, voltages, active faults, and temperature.

**Bus Voltages:** Alarm icon will appear on controller console and under "Active Faults" (see below) if any of these values are out of range:


- **24 Vdc:** Represents voltage from 24V power supply. Value is reported as on or off (0 or 24.0 volts). This supply is for external use via 24V I/O port.
- **15 Vdc and -15Vdc:** These are voltages that power the torque transducer for IAC & IPC controllers only
- **5 Vdc:** Represents voltage from 5V power supply powering controller electronics.
- **3.3 Vdc:** Represents controller electronics internal 3.3V Bus voltage
- **SOM 1.8 Vdc:** Represents controller electronics internal 1.8V Bus voltage
- **Mainboard 1.8 Vdc:** Represents controller electronics internal 1.8V Bus voltage
- **Torque Vdc:** Status indication of tool transducer voltage

**CPU Temperature (° C):** Represents temperature of CPU measured in Celsius.

**Mainboard Temperature (° C):** Represents temperature inside controller measures in Celsius.

**Active Faults:** Any tool/ controller faults will be shown in this area.

## 4.7.3 Live Tool



**Torque:** Shows a live view of tool transducer in volts. Voltage will be approximately 0 volts when tool is at rest and torque is zero. During a rundown, the tool transducer voltage increases as torque increases.

Encoder Signals will be monitored along with tool RPM. (Only applies for tools with Angle Sensing capability 'Resolver')


Signal Check is also available to force ON and OFF the following:

- Air Shut Off Valve solenoid
- CAL signal to the tool – When this is forced ON the torque voltage should be approximately 2 volts.

**Attention! Remove all forces before running the tool.**

## 4.7.4 Indicators

Allows user to test tool LEDs



## 4.7.5 Identify Controller

'Identify Controller' will cause lights on controller and tool to flash making the system easy to locate. This is especially helpful when programming is being done and multiple controllers are being used in close proximity to each other.

## 4.7.6 Record Logs

Log Records	
CHANGE	INFORMATION
ERROR	ALL

Logs information describing usage of controller and tools that have been used with that controller.

### 4.7.6.1 Change Log

Log displays changes made to tool or controller.

### 4.7.6.2 Information Log

Log displays all information entries.

### 4.7.6.3 Error Log

Log displays ONLY Error Entries.

### 4.7.6.4 All

Displays all Changes, Information, and Error entries.

## 4.7.7 System Status


System Status			
Memory Usage			
Startup	Current	Increase	
215712	246552	14.30%	
Internal Storage			
KB Allocated	KB Available	KB Used	
15620038	10934784	30%	
USB Flash Drive			
KB Allocated	KB Available	KB Used	
0	0	0	

## 4.7.8 I/O Diagnostics

The I/O Diagnostics screen shows a log of all IO state changes from any assignable input or output. This can aid in verifying the correct functionality for IO configuration.

Assignable I/O Diagnostics			
I/O	Bus	Assignment	I/O State
Out	24v	Job Complete	0
Out	24v	Angle Low	0
Out	24v	Angle High	0
Out	24v	Torque Low	0
Out	24v	Torque High	0
Out	24v	NOK	0
Out	24v	OK	0

The refresh button will update the screen with the most recent IO changes. The save button will generate a log file that can be viewed on a PC. This file can be downloaded when viewing from a PC or saved to a USB drive when using the controller touch screen. This saved CSV file contains much more detailed information (timing, IO settings, etc)



than can be displayed on the controller screen.

## 4.7.9 Network Diagnostics

Network Diagnostics can be useful in troubleshooting Ethernet communication issues

Network Diagnostics	
Ethernet	
	State Address
Ethernet 1	up 10.10.5.50
Ethernet 2	down
Test Connection	
IP Address	0.0.0.0 Ping
Capture	
Interface	All
Number of Packets	100
Start Capture	

**Ethernet:** Shows if the Ethernet port is physically connected and if the hardware is operational.

**Test Connection:** Provides a way to check the ethernet connection to other devices on the same network.

**Capture:** Captures and saves the ethernet traffic for evaluation




## 4.7.10 Statistics

Enter the desired number of samples and PSET to observe calculated statistics. Number of samples must be equal to or less than the existing recent results stored within the controller. Statistics are presented as a courtesy to users who wish to review them in quick fashion on the controller screen.

Statistics, 3 Samples		
	Torque	Angle
LSL	10.00 Nm	0°
Target	15.00 Nm	--
USL	20.00 Nm	0°
Min	32.42 Nm	4°
Max	45.87 Nm	132°
Range	13.45 Nm	128°
Low	0.0%	--
Ok	0.0%	--
High	100.0%	--
$\bar{x}$	41.33 Nm	88.77°
$\sigma$	7.72 Nm	73.04°
$\bar{x} - 3\sigma$	18.18 Nm	-130.35°
$\bar{x} + 3\sigma$	64.48 Nm	307.88°
$6\sigma$	46.31 Nm	438.23°
$6\sigma / \bar{x}$	1.12	4.94
Cp	0.22	--
Cpk	-0.92	--

Sample Size

PSet

The Lower Spec Limit (LSL) and Upper Spec Limit (USL) are the lowest and highest torque or angle values that should occur in the audit torque or angle stage. By default, the audit torque or angle stage is the last auditable stage. This can be changed in PSet → Edit Stage → Audit Options.

## 4.8 Login

When a password is required it can be entered in this screen.

Login

Login Password


Tip

See Advanced/Login Setup to configure default login levels.

Three levels of access to the controller are available:

- **Operator:** Run/Login/View PSet screens available.
- **Technician:** Run/PSet/Job/Diagnostics and Login screens available.
- **Administrator:** All screens available.

## 4.9 Advanced



The 'Advanced' menu handles complex settings within the controller. Detailed descriptions are given in the following sections.

### 4.9.1 Login Setup

This screen allows the user to select the default Login level upon controller start up.

Login Setup

Defaults

Login Level

Remote Login Level

Change Password


Administrator

Technician

- **Operator**
- **Technician**
- **Administrator**

The Remote Login Level sets the default login level for remote sessions, allowing administrators to avoid logging in when accessing the controller over the network.

## 4.9.2 Results Archive




Select a file and press

Approximately one million rundowns can be stored. Twenty files with approximately 50,000 rundowns are maintained at a time. The user can, at any time, save the runs to either a USB stick or to the Web as a CSV file imported directly into an Excel spreadsheet.

Using the touchscreen console, you can select multiple files to save.

Using the web option, you can select one of these files at a time to save (web option is default).

Select either USB or Web Archive location.




### Example of Saved Excel File

Rundown	Job Num	Job Name	Sequence	Bolt count	Status	Date	Time	Torque	Status	Angle	Status	PSet Num	PSet Nam	Tool Mod	Tool Serial	Id1 (ID #1)	Id2 (ID #2)	Id3 (ID #3)	Id4 (ID #4)
2068	0		0	0	P	#####	11:13:42	5.08	P	480	--	1			0				
2069	0		0	0	P	#####	11:13:49	5.054	P	535	--	1			0				
2070	0		0	0	P	#####	11:13:50	5.002	P	450	--	1			0				
2071	0		0	0	P	#####	11:13:52	5.013	P	595	--	1			0				
2072	0		0	0	P	#####	11:13:53	5.085	P	495	--	1			0				
2073	0		0	0	P	#####	11:13:54	5.1	P	440	--	1			0				
2074	0		0	0	P	#####	11:13:56	5.089	P	575	--	1			0				

## 4.9.3 Import Settings

This allows the user to download any previously saved settings onto the controller (refer to 'Export Controller' for help with saving data).

1. Plug the USB with an export file into any port on the controller.
2. From the Home screen, navigate to Advanced → Import Settings.
3. Select the settings to be checking the corresponding box



**Operations:** This includes PSets and Jobs.

**I/O:** This includes I/O settings for the local I/O, Anybus, Modbus, and EtherNet/IP.

**Configuration:** This includes all settings of the controller except I/O, Master Spindle, Rundowns, PSets or Jobs.



4. Press  to accept the changes.
5. Press  to proceed.
6. Press  when the import is complete and the controller will restart.


Import settings that were exported from another controller via a USB flash drive. Use this to quickly apply the same settings across several controllers. For example, it is common to have multiple controllers with the same I/O configuration. Set up one controller with the correct I/O configuration and export the controller from Advanced → Export Controller. Now the I/O settings can be imported using this screen.

**NOTE:** Setting can only be imported from controllers running the same version of software.

## 4.9.4 Export Controller

This allows the user to save Configuration, Operations, I/O, and Spindle settings onto a USB flash drive.

1. Plug a USB into any port on the controller.
2. From the Home screen, navigate to Advanced → Export Controller.
3. Press  to continue, and the controller will begin the export process.
4. Press  to complete the export.




## 4.9.5 Update Controller


**NOTE:** Updated firmware versions will typically be sent via email zip file. Always save PSet and IP address information before upgrading controller.


### Upgrading the AIMCO Gen IV Controller


Using the TouchScreen or a System Port browser session, navigate to the 'Advanced' menu. Click 'Update Controller.'



If a USB stick containing the zip file has been plugged in to the controller, the file will show in the

Available Updates list. Select the latest release and click  when ready.



If updating through a system port browser session, a dialog box will appear. Click the Choose File button and navigate to the folder where the zip file is located on the computer. Select the latest release and click  when ready.

After the controller restarts, the user should see following messages

### Updating System

**Do not unplug USB**

**Do not Power Off Controller**

**This may take a few minutes...**


*Controller Upgrade Notification*


When the controller has finished, navigate to Diagnostics → Controller Overview to view any changes to the 'Software Versions'. Any system settings (Ethernet IP address, PSets, Jobs, etc.) will remain unchanged.


## 4.9.6 Backup Restore

The Backup function allows the user to create an image of the controller software/firmware including all Configurations, Operations, I/O, and Spindle settings. This is used to create a point in which the controller can restore to if the need arises. In that case, the Restore function would be used.


1. From the Home screen, navigate to Advanced → Backup Restore.
2. Press Backup to initialize the backup process.




3. Press  to replace previous backup with current system, the backup process will begin.



4. Press **Restore** to initialize the restore process.


5. Press  to restore all settings and firmware to last backup, the restore process will begin.




6. The controller will restart when finished.

## 4.9.7 Restore Factory Defaults

This allows the user to reset the controller's parameters to factory settings


1. From the Home screen, navigate to Advanced → Restore Factory Defaults.
2. Select the settings to be changed and accept 


- **Configuration:** This includes all settings of the controller except I/O, Master Spindle, Rundowns, PSets or Jobs.
- **Operations:** This includes PSets and Jobs.
- **I/O:** This includes I/O settings for the local I/O, Anybus, Modbus, and Ethernet/IP.
- **Spindle:** This includes any Master Spindle setup (i.e. number of spindles, IP addresses, etc.).
- **Rundown:** This includes all rundown data/information
- **Log:** This includes the Change, Information, Error, and Combined logs.
- **Firmware:** This includes the firmware/software.
- **System:** This includes miscellaneous system files.




3. Press  to accept the changes.


4. Press  to proceed.



5. Press  when the calibration is complete, the controller will restart.



## 4.9.8 Previous Software




The 'Previous Software' page enables users to change the software to an alternate version. When the controller is updated, the previous version will be retained to easily revert


versions. Settings are not affected. Any changes to settings are retained when changing to an alternate version. The screen shows the current version along with the version information of the alternate version.

This feature is only available for versions 3R19 going forward. It is not possible to revert to a release earlier than 3R19.

## 4.9.9 Calibrate Touch Screen

Custom and Factory default calibration are available on the controller console.

1. From the Home screen, navigate to Advanced → Calibrate Touch Screen.
2. Press  to disable the tool.
3. Select the desired calibration






### Custom Calibration:

This allows the user to create a custom calibration setting for the touch screen.


### Factory Default Calibration:


This calibrates the touchscreen to the factory defaults.

4. Press  to accept the selection.
5. Press  to proceed.



In the case of custom calibration, a screen will appear with instructions on how to increase precision.



6. Press  when the calibration is complete, the controller will restart.


**NOTE:** The controller may need to be reset before the custom calibration is possible.


---

#### 4.9.10 Soft Reboot

---

Restart the controller without turning the power off.

1. From the Home screen, navigate to Advanced → Soft Reboot.
2. Press  to proceed, the controller will restart.



## 5. Barcode Reader Details

The iAC controller supports the following barcode reader functionality:

- Support up to four identifiers.
- Each rundown result can be associated with up to four identifiers.
- Identifier(s) can be used to select a parameter set or a job.
- Display identifier(s) on controller.
- Ability to lock-out tool until correct identifier(s) is entered.
- Ability to block barcode reads while a job is in progress.
- Barcode reads (identifiers) can come from any or all the following sources:
  - Serial barcode reader
  - Open protocol
  - Fieldbus network
  - Telnet port

### Solution

Regardless of the source (serial barcode reader, telnet, fieldbus, or protocol) each new string is passed through the same process:

- All four identifiers are reset to an empty string on power-up.
- Each received barcode is processed through a Barcode Match Table to look for a match, if one is found the barcode is accepted.
- Each fastening will then be associated with the received barcode(s) until a new one is received or they are reset.

### Parameters

The parameters that pertain to the processing of barcode strings:

- The Barcode Match Table is used to identify the newly received barcode string.
- Which of the four Identifiers (ID#1-4) are required to enable the tool?
- Which of the four Identifiers (ID#1-4) to reset on a job complete?
- Parameter to disable all barcode reads while a job is in progress. If set, barcode reads will be disabled after the first fastener is ran until job is complete.

### Barcode Match Table

The Barcode Match Table is used to identify which barcode has been received. The controller can have up to 99 entries (rows) in the table. Each entry has actions that will be performed when a matching barcode is received. The table is searched from top to bottom in an attempt to find a matching barcode. If none are found, the barcode is ignored.

### Mask

The Mask is a string used to compare against the received barcode. The received barcode must be at least as long in length as the Mask. The Mask can also contain "don't care" characters of a decimal point or period in the string. These "don't care" characters are counted in the length but the actual received character in that position doesn't matter.

### Identifier Type

The "Identifier Type" field identifies which identifier (ID#1-4) the received barcode will be stored in.

### Action

Action can be one of the following:

- None
- Select PS#1-256
- Select Job#1-20

### Reset ID

The "Reset ID" has the ability to reset other identifiers (ID#1-4) when barcode is received.

### Examples:

#### Operator Scans

When a vehicle enters the station, the operator scans the VIN. The controller selects the correct job number and enables the tool. Each fastener will be identified with this VIN stored locally, and/or sent to a server for storage. The job settings will disable the tool when the job is complete.

#### Setup

In this example, there are three possible vehicle types each with its own job. The barcode scan will select the correct job (enabling the tool) and the scan will be stored into ID#1.

Mask	ID type	Action		Reset ID			
				ID#1	ID#2	ID#3	ID#4
"VIN.....7..."	ID#1	Select Job#	1	No	No	No	No
"VIN.....8..."	ID#2	Select Job#	2	No	No	No	No
"VIN.....9..."	ID#3	Select Job#	3	No	No	No	No



The tool enable/disable will be controlled by the job settings; the correct job will be selected by the barcode scan. The "ID Required to Enable the Tool" feature does not need to be utilized.

Required Identifiers for Tool Enable			
ID#1	ID#2	ID#3	ID#4
No	No	No	No

These settings are irrelevant since the only way to enable the tool is with a new job and the only way to select a new job is to scan a new barcode.

Reset Identifiers on Job Complete			
ID#1	ID#2	ID#3	ID#4
Yes	No	No	No

### Examples

This is what the 'Operator Scans' example looks like once set up in the Barcode Configuration Screen (see "4.5.7 Bar Code Setup" on page 30).

### Airbag Install

The customer wants to track the serial number of each airbag being installed, as well as the operator installing it. When the operator reports to the station, they will scan their employee ID. When the vehicle comes into the station, the operator scans the VIN of the vehicle and the serial number of the airbag. Once all three scans are received, the tool is enabled. Once the correct number of fasteners are installed, the tool is disabled by the job settings. From that point, the operator only needs to scan the vehicle and the airbag to enable the tool.

### Setup

We will assign the employee ID to ID#1, the vehicle VIN to ID#2, and the airbag serial number to ID#3. Scanning a new employee ID will reset the other IDs and force a scan of the vehicle VIN and airbag serial number. The scan of the vehicle VIN will also select the correct job number.

Mask	ID type	Action	Reset ID			
			ID#1	ID#2	ID#3	ID#4
"EMP...."	ID#1	None	No	Yes	Yes	No
"VIN....."	ID#2	Select Job#	1	No	No	No
"SN....."	ID#3	None	No	No	No	No


Once all three scans are received, the tool will be enabled.

Required Identifiers for Tool Enable			
ID#1	ID#2	ID#3	ID#4
Yes	Yes	Yes	No

When job is complete, the vehicle VIN will be reset and the airbag serial number, but not the employee ID; this way subsequent vehicles will only require a VIN and S/N to enable tool.

Reset Identifiers on Job Complete			
ID#1	ID#2	ID#3	ID#4
No	Yes	Yes	No

This is what the Airbag Install example looks like set up in "4.5.7 Bar Code Setup" on page 30.

























6. Glossary of Terms

<b>Accept Tone</b>	Controls tone made from handle of handheld tools for accepted fastening cycles.
<b>Angle</b>	Degree fastener rotates from snug, or threshold level, to peak torque.
<b>Cycle Complete</b>	Torque level that determines completion of a fastening cycle.
<b>High Angle</b>	When peak angle recorded exceeds High Angle, the fastening cycle is recorded as a reject for High Angle, the High Angle light (solid yellow) illuminates and fastening cycle is given an overall status of NOK.
<b>High Torque</b>	When peak torque recorded exceeds the High Torque, the fastening cycle is recorded as a reject for High Torque, the High Torque light (solid red) illuminates and fastening cycle is given an overall status of NOK.
<b>High Pulse</b>	When pulse count recorded exceeds the High Pulse, the fastening cycle is recorded as a reject for High Pulse, the High Pulse light (solid yellow) illuminates and fastening cycle is given an overall status of NOK.
<b>Job</b>	A Job is a collection of PSets or Multi-stages, which are useful when performing several multiple fastening operations, each with different requirements. This is convenient since the operator does not have to select a new PSet or Multistage for every fastening.
<b>Low Angle</b>	When the peak angle recorded during the Angle Audit Step fails to reach the Low Angle, fastening cycle is recorded as a reject for Low Angle, the low angle light (flashing yellow) illuminates and fastening cycle is given an overall status of NOK.
<b>Low Torque</b>	When the peak torque recorded fails to reach the Low Torque, fastening cycle is recorded as a reject for Low Pulse, the Low Pulse light (flashing yellow) illuminates and fastening cycle is given an overall status of NOK.
<b>Low Pulse</b>	When the pulse count recorded fails to reach the Low Pulse, fastening cycle is recorded as a reject for Low Torque, the Low Torque light (flashing red) illuminates and fastening cycle is given an overall status of NOK.
<b>Parameter Set</b>	A Parameter Set is a collection of instructions that define how the tool should perform the fastening process. It may be selected from the console or device such as a socket tray or PC

<b>In-Cycle Torque</b>	Controller begins to monitor tool for angle at a preselected threshold torque. Any increase in angle, after the In-Cycle point, results in a corresponding increase in tension or clamp load within the joint.
<b>Speed</b>	Speed at which tool operates during the initial portion of the fastening cycle prior to downshift.
<b>Spindle</b>	A spindle represents a connection to a handheld, or fixtured, tool connected to a controller.
<b>Strategy</b>	Identifies the variables being used to control tool during a fastening.
<b>Threshold Torque</b>	Sets point at which tool is "In Cycle".
<b>Torque Calibration</b>	Determines how torque values are assigned to the electrical signals for torque transducer on tool. Value is unique to each tool and changes over time.
<b>Torque Target</b>	When the tool is being controlled for torque, the torque target instructs controller when to shutoff tool. Torque target should be greater than Low Torque and less than High Torque, this is required for torque control.














7. Icons Defined












Icon	Description	Function	Where Used
	Home Navigation Button	Navigate to the main menu ("HOME") screen.	All screens except for edit screens.
	Run Navigation Button	Navigate to the Run Screen.	All screens except for edit screens.
	Run Screen Select Buttons	Switch between the different run screen pages.	Run Screen
	Go Back Button	Navigate to one menu level back.	All screens except for edit screens.
	Accept Changes Button	Accept the changes made and return to the parent screen.	Edit screens
	Cancel Changes Button	Reject the changes made and return to the parent screen.	Edit screens
	Add New Button	Add a new item (Pset, Stage, Job, and other).	PSet and Job edit screens.
	Edit Button	Edit selected Item.	PSet and Job edit screens.
	Move Up and Down Buttons	Move selected item up or down in the sequence order.	PSet and Job edit screens.
	Copy Button	Copy selected Items	PSet, Job, and other edit screens.
	Delete Button	Remove or un-assign selected items.	Edit and list view screens.
	Filter Button	Filter Items in a list or table.	List view screens
	Save Button	Save selected item to file.	List view screens
	Select Columns Button	Allows customization of columns shown on the Results Screen.	Results Screen
	Fault Indicator	Fault exists that is preventing the tool from running (can be pressed for more Info).	Run Screen
	Invalid PSet Indicator	Selected Pset does not exist or is not valid.	Run Screen

Icon	Description	Function	Where Used
	Barcode Scan Required Indicator	A barcode is required to enable the tool.	Run Screen
	Job Complete Indicator	Job is complete.	Run Screen
	Lock on Reject (LOR)	Lock tool on rejected fastener.	Run Screen
	Disassembly	A disassembly event has been detected.	Run Screen
	Job Reset Complete	Reset Job has finished. Results from last successful rundown of a job are cleared.	Add New Job Screen
	Scan	Search for accessories on the network	Add Accessories Screen

## 8. Stop Codes

If a Stop condition is detected that prevents the tool from running, a code will appear on the LED display. Any active stop conditions are also displayed on the RUN screen.

Code	Icon	Description
<b>IO</b>		Stopped or Disabled from Physical 24 volt IO input
<b>ABUS</b>		Stopped or Disabled from ANYBUS
<b>MODB</b>		Stopped or Disabled from Modbus
<b>EIP</b>		Stopped or Disabled from Ethernet IP
<b>RTU</b>		Stopped or Disabled from Modbus RTU
<b>OP</b>		Stopped or Disabled from Open Protocol
<b>OP</b>		Lost Open Protocol Connection
<b>REV</b>		Disassembly Disabled
<b>ARM</b>		Tool Requires Arming – MFB button configured to enable the tool to run.
<b>JOB</b>		Job Sequence Complete
<b>JOB</b>		Job Complete
<b>JOB</b>		XML Count Complete
<b>LOR</b>		Locked on Reject

Code	Icon	Description
<b>BRCD</b>		Bar Code ID scan required to enable tool
<b>SRVC</b>		Tool Disabled For Service - Tool service or calibration interval has expired
<b>INVP</b>		Invalid PSet - Parameter set number for a non-existent Pset has been selected to run. Most likely via one of the following methods: <ul style="list-style-type: none"> <li>○ Job</li> <li>○ MFB</li> <li>○ I/O</li> </ul>
<b>INVP</b>		PSet outside of Job - Parameter set number outside of the job has been selected. Most likely via one of the following methods: <ul style="list-style-type: none"> <li>○ MFB</li> <li>○ I/O</li> </ul>
<b>INVJ</b>		Invalid Job - Job number for a non-existent Job has been selected to run. Most likely via one of the following methods: <ul style="list-style-type: none"> <li>○ MFB</li> <li>○ I/O</li> </ul>
<b>PSET</b>		PSet Mismatch
<b>SPND</b>		Spindle Not Configured – Spindle selected to run from a Multi-Spindle Job has not been configured
<b>NET</b>		XML Disconnected
<b>XML</b>		Stop from XML
<b>NOK</b>		XML Max Rejects Exceeded
<b>FLT</b>		Controller Fault - Error has been detected. See fault code list for details

## 9. Error Codes


If an error condition is detected that prevents the tool from running, a fault code will appear on the LED display. Any active faults are also displayed on GUI RUN screen. Fault history can be viewed in the Controller Error Log.

Code	Fault Type	Description	Possible Causes
Gen IV Common Hardware Fault Codes			
<b>FH17</b>	1.8vdc MB out of tolerance	Main board 1.8 bus voltage exceeds electrical limits	<ul style="list-style-type: none"> <li>Faulty Controller main board or other Controller electronics</li> </ul>
<b>FH18</b>	1.8vdc SOM out of tolerance	System on Module 1.8 bus voltage exceeds electrical limits	<ul style="list-style-type: none"> <li>Faulty Controller main board or other Controller electronics</li> </ul>
<b>FH19</b>	3.3vdc out of tolerance	Main board 3.3 bus voltage exceeds electrical limits	<ul style="list-style-type: none"> <li>Faulty Controller main board or other Controller electronics</li> </ul>
<b>FH20</b>	5vdc out of tolerance	5 Volt bus voltage out of range	<ul style="list-style-type: none"> <li>Faulty power supply or wiring</li> <li>Faulty Controller main board or other Controller electronics</li> </ul>
<b>FH21</b>	9vdc out of tolerance	9 Volt bus voltage out of range	<ul style="list-style-type: none"> <li>Faulty power supply or wiring</li> <li>Faulty Controller main board or other Controller electronics</li> <li>Faulty tool cable</li> <li>Faulty tool electronics or wiring</li> </ul>
<b>FH22</b>	24 volt level low	24 Volt I/O power not detected	<ul style="list-style-type: none"> <li>Faulty power supply or wiring</li> <li>Short or other problem with external connections to the 24Volt I/O port.</li> </ul>
<b>FH23</b>	Controller temp high	Controller's internal temperature exceeds limit	<ul style="list-style-type: none"> <li>Ambient air temperature exceeds rating of Controller</li> </ul>
<b>FH24</b>	+15vdc out of tolerance	+15 Volt bus voltage out of range	<ul style="list-style-type: none"> <li>Faulty power supply or wiring</li> <li>Faulty Controller main board or other Controller electronics</li> <li>Faulty tool cable</li> <li>Faulty tool electronics or wiring</li> </ul>
<b>FH25</b>	-15vdc out of tolerance	-15 Volt bus voltage out of range	<ul style="list-style-type: none"> <li>Faulty power supply or wiring</li> <li>Faulty Controller main board or other Controller electronics</li> <li>Faulty tool cable</li> <li>Faulty tool electronics or wiring</li> </ul>
<b>FH32</b>	Processor Fault	RTOS processor not communicating with the Application processor	<ul style="list-style-type: none"> <li>Faulty mainboard electronics</li> <li>RTOS processor firmware corrupted or not loaded</li> <li>Faulty SOM board or connector</li> </ul>
iAC Specific Fault Codes			
<b>FA01</b>	Torque signal out of Range	Tool torque signal voltage is beyond electrical limits	<ul style="list-style-type: none"> <li>Tool not connected</li> <li>Faulty tool cable</li> <li>Faulty transducer</li> <li>Transducer electronics not calibrated</li> <li>Faulty tool electronics or wiring</li> </ul>
<b>FA02</b>	Torque tare value out of range	Tool torque signal no load voltage is out of range	<ul style="list-style-type: none"> <li>Tool not connected</li> <li>Faulty tool cable</li> <li>Faulty transducer</li> <li>Transducer electronics significantly out of calibration</li> <li>Faulty transducer</li> </ul>
<b>FA03</b>	Torque Cal signal out of Range	Tool does not respond to the full scale voltage CAL single	<ul style="list-style-type: none"> <li>Tool not connected</li> <li>Faulty tool cable</li> <li>Faulty transducer</li> <li>Transducer electronics not calibrated</li> <li>Faulty tool electronics or wiring</li> </ul>

## 10. 24 Volt I/O

### Port Pinout and Diagrams

An I/O wiring adapter kit is available (Part #27348) from AIMCO to make connection to I/O port on the controller easier. Contact your AIMCO Sales Representative for ordering information. Toll Free: 1-800-852-1368.



Pin #	Function	Default Assignment
1	Output 1	Accept
2	Output 2	Reject
3	Output 3	In Cycle
4	Output 4	Torque High
5	Outputs 1-4 common	
6	Input 1	N/C
7	Input 2	N/C
8	Input 3	Disable Tool
9	Input 4	PSet Bit 1
10	Input 5	PSet Bit 2
11	Input 6	PSet Bit 3
12	Input 7	Reset Job
13	Input 8	
14	Output 5	Torque Low
15	Output 6	Angle High
16	Output 7	Angle Low
17	Output 8	Job Complete
18	Outputs 5-8 common	
19	N/C	
20	N/C	
21	24 V Return	
22	24 V Return	
23	+24 Vdc	
24	+24 Vdc	
25	+24 Vdc	

**NOTE:** The Default Assignments in Table above are factory defaults and can be changed. See "11. Assignable I/O" on page 48.


### 24 Volt I/O Connections

Turn off system before connecting to the LOGIC I/O port. There may be risk of damaging the controller.


- **24Vdc Supply:** The internal 24Vdc power can supply up to 1 amp.
- **Inputs:** Inputs are a sinking configuration with the common connected to the ground pins. 24Vdc is logic ON and 0Vdc is logic OFF.
- **Outputs:** Outputs are normally open relay contacts. The relays are rated for 24Vdc, 1 amp.

**NOTE:** If Outputs are driving an inductive load, such as a solenoid or large relay, it is recommended to add a diode in parallel with the load to prevent voltage surges.

#### LOGIC I/O INPUT CONNECTION EXAMPLE




#### LOGIC I/O OUTPUT CONNECTION EXAMPLE




## Importing I/O on an iEC4

These instructions detail how to import I/O into an iEC4 controller via the system port to modify the Anybus outputs.

1. Power on the controller
2. Insert the USB stick into a USB port
3. Connect to the controller via system port and web browser (default address 192.168.1.4)
4. Navigate to Advanced → Import Settings



5. Choose file and select **ONLY I/O**



6. Click OK
7. Click OK in the Confirmation dialog box
8. The controller will restart
9. Verify the Anybus outputs.
  - a. Navigate to Controller → IO → Anybus Outputs
  - b. Click on the first row of element #1 and verify it is set as 'Running Job Number', Bit 0, Bits 8, Start at 0.
  - c. Click on element #4 and verify it is set as "Torque (x100)", Bit 0, Bits 16



## 11. Assignable I/O

The Gen IV controller supports assignable I/O.

**Buses:** The controller is divided up into buses. Each bus has a set of inputs and a set of outputs. Currently the controller supports the following buses.

Bus Number	Bus
1	Physical I/O
2	Fieldbus (Anybus module) I/O
3	Modbus TCP
4	Ethernet/IP

All assignments have a bus, element, and bit configuration to define its location in the system. The bus value needs to be set from the list above. The element and bit define the location in the bus. The first element on the bus is 0 and goes up the last legal element for the given bus. The bits in each element is referenced from 0(LSB) to 31(MSB).

### Inputs

All input assignments have a Bus, Element, and Bit configuration to define its location in the system. Along with the basic configuration many also have other configuration(s) that allow its behavior to be modified to suit the application.

	Supported Feature						Controllers				
	Bus	Element	Bit 0-31	Polarity N.O./N.C.	Width	Offset	iEC	iAC	iPC	iBC	iBC-Z
Do Nothing	√	√	√				√	√	√	√	√
Start	√	√	√	√			√				
Stop	√	√	√	√			√	√	√	√	
Reverse	√	√	√	√			√				
Disable	√	√	√	√			√	√	√		
Reset Job	√	√	√	√			√	√	√	√	√
Select PSet	√	√	√		√	√	√	√	√	√	
Select Job	√	√	√		√	√	√	√	√	√	√
Select Job Sequence	√	√	√		√	√	√	√	√	√	√
Disable Assembly	√	√	√	√			√				
Set ID	√	√	√		√		√	√	√	√	√
Set ID (word swap)	√	√	√		√		√	√	√	√	√
Set Date/Time	√	√	√		√		√	√	√	√	√
Set Date/Time (word swap)	√	√	√		√		√	√	√	√	√
Verify PSet	√	√	√		√	√	√	√	√	√	√
Clear Results	√	√	√	√			√	√	√	√	√
Log Change	√	√	√		√	√	√	√	√	√	√
Decrement Batch	√	√	√	√			√	√	√	√	√
Increment Batch	√	√	√	√			√	√	√	√	√
Click Wrench	√	√	√	√			√	√	√	√	√
Click Wrench NOK	√	√	√	√			√	√	√	√	√
Bypass Stops	√	√	√	√			√	√	√	√	√
Verify Job Sequence	√	√	√		√	√	√	√	√	√	√
ASCII ID	√	√					√	√	√	√	√
Abort Job	√	√	√	√			√	√	√	√	
Remote Start	√	√	√	√			√				
Remove Lock on Reject	√	√	√	√			√	√	√	√	
Dual Start Interlocked	√	√	√	√			√				
Decrement Job	√	√	√	√			√	√	√	√	√
Increment Job	√	√	√	√			√	√	√	√	√
Decrement PSet	√	√	√	√			√	√	√	√	√
Increment PSet	√	√	√	√			√	√	√	√	√
Decrement Job Sequence	√	√	√	√			√	√	√	√	√
Increment Job Sequence	√	√	√	√			√	√	√	√	√
Set Tool Home Position	√	√	√	√			√				



## Polarity

When the polarity is set to N.O. the input is considered active high (24vdc for physical inputs and logic 1 for all network type buses). When the polarity is set to N.C. the input is considered active low (0vdc for physical inputs and logic 0 for all network type buses).

## Width and Offset

For multiple bit inputs (for example "Select PSet") the width variable defines the number of bits the assignment will read for its input. This allows the input size to be restricted to a few bits saving space for other assignments.

The offset variable allows a fixed value to be added to the read value.

For example to use bits 4 & 5 of the physical inputs to select parameter sets 1-4 the assignment would look like...

Select PSet		
Bus	1	For the physical bus
Element	0	For the first element on the bus
Bit	4	For the starting bit location
Width	2	To span the two bits 4 & 5
Offset	1	Adding 1 to the read input value so we get... Binary 00 = 1 Binary 01 = 2 Binary 10 = 3 Binary 11 = 4

## Input Assignments

Do Nothing	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√			
The "Do Nothing" assignment will run do nothing if it is active or inactive.						
Start	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		
The "Start" assignment will run the tool while the input is active. Start is available for the Physical I/O bus only.						
Stop	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		
The "Stop" assignment will stop the tool if it is running and prevent it from being started.						

Reverse	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		
The "Reverse" will put the controller in disassembly mode while the input is active.						
Disable	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		
The "Disable" will disable the tool while the input is active. It will not stop a fastening cycle that is progress.						
Reset Job	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		
On the transition of inactive to active the "Reset Job" assignment will reset the active job.						
Select PSet	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	√
The "Select PSET" input will select the parameter set according to the input value. Uses the width parameter limit the width of the input bits read. The minimum width is 1 and the maximum is 8. After the input is read the offset parameter will be added to the value do get the actual parameter set number. Selecting an invalid parameter set number will disable the tool.						
Select Job	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	√
The "Select Job" input will select the job number according to the input value. Uses the width parameter limit the width of the input bits read. The minimum width is 1 and the maximum is 8. After the input is read the offset parameter will be added to the value do get the actual job number. Selecting an invalid job number will disable the tool.						
Select Job Sequence	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	√
The "Select Job Sequence" input will select the job sequence number according to the input value. Uses the width parameter limit the width of the input bits read. The minimum width is 1 and the maximum is 8. After the input is read the offset parameter will be added to the value do get the actual job sequence number. Selecting an invalid job sequence number or a sequence that is already complete will disable the tool.						

Disable Assembly	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Disable Assembly" assignment will disable the tool in the assembly direction. It will not disable the tool in disassembly or tube nut homing. It will not stop a fastening cycle that is progress.

Set ID	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	

The "Set ID" assignment will set the ID to an integer value of the input value. The width can be set from 1 to 32 bits. The input value will read as an integer value and an ASCII string with leading zeros will be produced and passed to the ID recognition system. The length of the string is based on the width of the assignment. The string will always be sized to accommodate the maximum value of the input. For example a width setting of 16 can have an integer value of 0-65535 so the produced ID would be "00000" to "65535" (always five character long).

Width setting	Length of ID string	ID value
1 - 3	1	"0" - "n"
4 - 6	2	"00" - "nn"
7 - 9	3	"000" - "nnn"
10 - 13	4	"0000" - "nnnn"
14 - 16	5	"00000" - "nnnnn"
17 - 19	6	"000000" - "nnnnnn"
20 - 23	7	"0000000" - "nnnnnnn"
24 - 26	8	"00000000" - "nnnnnnnn"
27 - 29	9	"000000000" - "nnnnnnnnn"
30 - 32	10	"0000000000" - "nnnnnnnnnn"

Set ID (word swap)	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	

The "Set ID (word swap)" assignment is the same as the "Set ID" assignment except the high and low words (16bit) are swapped prior to evaluation. This is to correct the mixed endianness of some PLC. See the "Set ID" for behavior.

Set Date/Time	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	

The "Set Date/Time" assignment will set the date and time of the controller. The width can be set from 1 to 32 bits but should always be set to 32 to get the correct results. The input value will be read as the number of seconds since 00:00:00 January 1, 1970 (POSIX time or Epoch time). If the input value changes and it is non-zero the date and time of the controller will be set to the new value.

Set Date/Time (word swap)	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	

The "Set Date/Time (word swap)" assignment is the same as the "Set Date/Time" assignment except the high and low words (16bit) are swapped prior to evaluation. This is to correct the mixed endianness of some PLC. See the "Set Date/Time" for behavior.

Verify PSet	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	√

The "Verify PSET" input will compare the current parameter set to the input value. Uses the width parameter limit the width of the input bits read. The minimum width is 1 and the maximum is 8. After the input is read the offset parameter will be added to the value to get the actual parameter set number. If the parameter set input value does not match the current parameter of the controller the tool will be disabled.

Clear Results	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Clear Results" assignment will clear the latest results outputs (Ok, Nok, etc.) on the same bus.

Log Change	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	√

The "Log Change" assignment will add entries to the controller event log when the input changes.

Decrement Batch	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Decrement Batch" assignment will remove the latest OK rundown from the current running JOB. This will cause the JOB count to be reduced by one.

Increment Batch	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Increment Batch" assignment will insert a manual rundown into the current sequence of the current JOB. This will cause the JOB count to increment by one.

Click Wrench	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Click Wrench" assignment is the same as "Increment Batch" with the addition of a programmable torque value.

Click Wrench NOK	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Click Wrench NOK" assignment is the same as "Click Wrench," but the inserted manual rundown always reports a torque of 0.

Bypass Stops	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Bypass Stops" assignment removes most stop conditions, allowing the tool to be ran in an override type condition. Hardware faults, stop and disable inputs are not removed.

Verify Job Sequence	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√		√	√

The "Verify Job Sequence" input will compare the current Job sequence to the input value. Uses the width parameter limit the width of the input bits read. The minimum width is 1 and the maximum is 8. After the input is read the offset parameter will be added to the value do get the actual Job sequence number. If the Job sequence input value does not match the current Job sequence of the controller the tool will be disabled.

ASCII ID	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√				

The "ASCII ID" assignment will set the ID to the of the input (ASCII) value. This assignment consumes the entire element so the Bit is not used. It also has a length parameter to set the length of the input in bytes. The input value will be passed directly to the ID recognition system.

Abort Job	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Abort Job" assignment aborts the job and disables the tool. A job reset is required to enable the tool for the next job.

Remote Start	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Remote Start" assignment will run the tool while the input is active. Remote Start is available for non-physical I/O buses.

Remove Lock on Reject	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Remove Lock on Reject" assignment unlocks the tool if locked on reject, re-enabling the tool.

Dual Start Interlocked	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Dual Start Interlocked" assignment will run the tool if the interlock conditions are met. Dual Start Interlock is available for the Physical IO bus only. The Dual Start Interlocked input works in combination with the Physical input assigned to the 'Start' input. The Dual Start Interlocked is only available for iEC controllers.

#### Setup

- Only 1 Start Input and 1 Dual Start Interlocked Input should be assigned.
- Controller->Tool Setup -> Start Input Configuration:
  - The Start Input Source Must be set to 'Start From IO'.
  - Latching throttle is disabled for Dual Interlocked Start.

#### Dual Start Interlocked - Operation

- The tool will not run unless both inputs are activated within two seconds of each other.
- If the two second timer times out, both inputs must be deactivated to reset the timer.
- If either input is deactivated the tool stops.
- To restart the tool, both inputs must be deactivated then reactivated within two seconds of each other.

#### Tubenuit Tool Homing Exceptions for Dual Start Interlocked functionality

- If controller's tubenuit homing configuration is set to RELEASE:
  - Deactivating either, or both, of the inputs will initiate the homing sequence.
  - Homing will continue until sequence is complete.
- If controller's tubenuit homing configuration is set to RELEASE AND REPRESS:
  - Deactivating either of the inputs, then activating both inputs will initiate the homing sequence.
  - Homing will continue while both inputs are active.
  - If either input is deactivated, before homing is complete, the tool will stop, and homing will pause until both inputs are reactivated.
  - To restart tool, after homing is complete, both inputs must be deactivated, then reactivated within two seconds of each other.

Decrement Job	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Decrement Job" assignment will decrement the Job Number, selecting the last job if decrementing past the first one.

Increment Job	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Increment Job" assignment will increment the Job Number, selecting the first job if incrementing past the last one.

Decrement PSet	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Decrement PSet" assignment will decrement the PSet Number, selecting the last PSet if decrementing past the first one.

Increment PSet	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Increment PSet" assignment will increment the PSet Number, selecting the first PSet if incrementing past the last one.

Decrement Job Sequence	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Decrement Job Sequence" assignment will decrement the Job sequence, selecting the last job sequence if decrementing past the first one.

Increment Job Sequence	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Increment Job Sequence" assignment will increment the Job sequence, selecting the first job if incrementing past the last one.

Set Tool Home Position	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Width	Offset
	√	√	√	√		

The "Set Tool Home Position" assignment will set the home position to the tool's current angular location. This can be used in conjunction with the Homing stage to bring the tool's output back to the home position.

# AcraDyne Gen IV iAC Controller Manual

## Outputs

All output assignments have a Bus, Element, and Bit configuration to define its location in the system. Along with the basic configuration many also have other configuration(s) that allow its behavior to be modified to suit the application.

	Supported Feature											Controller				
	Bus	Element	Bit 0-32	Polarity N.O./ N.C.	Mode Normal, Timed, Flashed	Time	Width	Offset	Input Bus	Input Element	Input Bit	iEC	iAC	iPC	iBC	iBC-Z
Ok	√	√	√	√	√							√	√	√	√	√
Nok	√	√	√	√	√							√	√	√	√	√
Torque Ok	√	√	√	√	√							√	√	√	√	√
Torque Nok	√	√	√	√	√							√	√	√	√	√
Low Torque	√	√	√	√	√							√	√	√	√	√
High Torque	√	√	√	√	√							√	√	√	√	√
Angle Ok	√	√	√	√	√							√	√	√	√	√
Angle Nok	√	√	√	√	√							√	√	√	√	√
Low Angle	√	√	√	√	√							√	√	√	√	√
High Angle	√	√	√	√	√							√	√	√	√	√
Fastening Complete	√	√	√	√	√							√	√	√	√	√
In Cycle	√	√	√	√	√							√	√	√		
Fastening Aborted	√	√	√	√	√							√	√	√	√	√
Fastening Stopped	√	√	√	√	√							√	√	√	√	√
Batch Complete	√	√	√	√	√							√	√	√	√	√
Job Complete	√	√	√	√	√							√	√	√	√	√
Error	√	√	√	√	√							√	√	√	√	√
Tool Start Switch	√	√	√	√	√							√				
Tool Push to Start Switch	√	√	√	√	√							√				
Tool MFB	√	√	√	√	√							√				
Tool Enabled	√	√	√	√	√							√	√	√	√	√
Tool Running	√	√	√	√	√							√	√	√		
Service Indicator	√	√	√	√	√							√	√	√		√
ToolsNet Connected	√	√	√	√	√							√	√	√	√	√
Open Protocol Connected	√	√	√	√	√							√	√	√	√	√
PFCs Connected	√	√	√	√	√							√	√	√	√	√
Running PSet Number	√	√	√				√	√				√	√	√	√	√
Running Job Number	√	√	√				√	√				√	√	√	√	√
External Controlled	√	√	√						√	√	√	√	√	√	√	√
Tool In CCW	√	√	√	√	√							√	√	√		
Tool In CW	√	√	√	√	√							√	√	√		
Torque	√	√	√				√					√	√	√	√	√
Torque (x10)	√	√	√				√					√	√	√	√	√
Torque (x100)	√	√	√				√					√	√	√	√	√
Angle	√	√	√				√					√	√	√	√	√
Rundown Saved to FTP Server	√	√	√				√					√	√	√	√	√
Fastener Removed	√	√	√	√	√							√	√	√		
Spindle Ok	√	√	√	√	√							√				
Spindle NOK	√	√	√	√	√							√				
Spindle Fastening Complete	√	√	√	√	√							√				
Pulses	√	√	√				√						√	√		√
Pulses High	√	√	√	√	√								√	√		√
Pulses Low	√	√	√	√	√								√	√		√
Pulses NOK	√	√	√	√	√								√	√		√
Pulses Ok	√	√	√	√	√								√	√		√
ON	√	√	√	√	√							√	√	√	√	√
Job Aborted	√	√	√	√	√							√	√	√	√	
Tool In Use	√	√	√	√			√					√	√	√	√	√
Barcode Scanned	√	√	√	√								√	√	√	√	√
Start Trigger Active	√	√	√	√								√				

## Polarity

When the polarity is set to N.O. the output will be high when it is active (24vdc for physical outputs and logic 1 for all network type buses). When the polarity is set to N.C. the output will be low for active (0vdc for physical inputs and logic 0 for all network type buses).

## Mode

### **Normal**

In the "Normal" mode the output will track the state of the assignment (while still observing the polarity setting). If the polarity is set N.O. and the assignment has an active output the output will be on and stay on till the assignment goes to inactive.




Figure 1: Normal Mode

### **Timed**

In the "Timed" mode the output will come on when the assignments state goes active and go off based on the time value or the assignment state going inactive (while still observing the polarity setting).




Figure 2 Timed Mode




Figure 3: Timed Mode (assignment deactivates before time expires)

### **Flash**

In the "flash" mode the output will flash at the time rate while the assignments state is active (while still observing the polarity setting).




Figure 3 Flash Mode

### Width and Offset

For multiple bit outputs (for example "Running PSet Number") the width variable defines the number of bits the assignment will output. This allows the output size to be restricted to a few bits saving space for other assignments.

The offset variable allows a fixed value to be added to the value before it is output.

For example to use bits 4 & 5 of the physical outputs to indicate the selected parameter set number 1-4 as binary 0-3 the assignment would look like...

Running PSet Number		
Bus	1	For the physical bus
Element	0	For the first element on the bus
Bit	4	For the starting bit location
Width	2	To span the two bits 4 & 5
Offset	-1	Adding -1 to the read input value so we get... 1 = Binary 00 2 = Binary 01 3 = Binary 10 4 = Binary 11

## Output Assignments

	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
<b>OK</b>	√	√	√	√	√						

The "Ok" output assignment will go active at the completion of an acceptable fastening. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>Nok</b>	√	√	√	√	√						
------------	---	---	---	---	---	--	--	--	--	--	--

The "Nok" output assignment will go active at the completion of an unacceptable fastening. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>Torque Ok</b>	√	√	√	√	√						
------------------	---	---	---	---	---	--	--	--	--	--	--

The "Torque Ok" output assignment will go active at the completion of a fastening that has an acceptable torque value. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>Torque Nok</b>	√	√	√	√	√						
-------------------	---	---	---	---	---	--	--	--	--	--	--

The "Torque Nok" output assignment will go active at the completion of a fastening that has an unacceptable torque value. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>Low Torque</b>	√	√	√	√	√						
-------------------	---	---	---	---	---	--	--	--	--	--	--

The "Low Torque" output assignment will go active at the completion of a fastening that has a low torque results. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>High Torque</b>	√	√	√	√	√						
--------------------	---	---	---	---	---	--	--	--	--	--	--

The "High Torque" output assignment will go active at the completion of a fastening that has a high torque results. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>Angle Ok</b>	√	√	√	√	√						
-----------------	---	---	---	---	---	--	--	--	--	--	--

The "Angle Ok" output assignment will go active at the completion of a fastening that has an acceptable angle results. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>Angle Nok</b>	√	√	√	√	√						
------------------	---	---	---	---	---	--	--	--	--	--	--

The "Angle Nok" output assignment will go active at the completion of a fastening that has an unacceptable angle results. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>Low Angle</b>	√	√	√	√	√						
------------------	---	---	---	---	---	--	--	--	--	--	--

The "Low Angle" output assignment will go active at the completion of a fastening that has a low angle results. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

<b>High Angle</b>	√	√	√	√	√						
-------------------	---	---	---	---	---	--	--	--	--	--	--

The "High Angle" output assignment will go active at the completion of a fastening that has high angle results. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.

# AcraDyne Gen IV iAC Controller Manual

<b>Fastening Complete</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Fastening Complete" output assignment will go active at the completion of a fastening. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.											
<b>In Cycle</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "In Cycle" output assignment will go active at the start of the fastening cycle (the torque exceeds the threshold value). It will go inactive when the fastening cycle ends.											
<b>Fastening Aborted</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Fastening Aborted" output assignment will go active at the completion of a fastening that was aborted by the system. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.											
<b>Fastening Stopped</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Fastening Stopped" output assignment will go active at the completion of a fastening that was stopped by the user. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.											
<b>Batch Complete</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Batch Complete" output assignment will go active at the completion of a fastening that satisfies the bolt count of a Job sequence. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or the job is reset.											
<b>Job Complete</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Job Complete" output assignment will go active at the completion of a fastening that satisfies all the sequences. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or the job is reset.											
<b>Error</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Error" output assignment will be active while the controller has an error.											
<b>Tool Start Switch</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Tool Start Switch" output assignment will reflect the state of the tools start lever.											
<b>Tool Push to Start Switch</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Tool Push to Start Switch" output assignment will reflect the state of the tools push to start switch.											
<b>Tool MFB</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Tool MFB" output assignment will reflect the state of the tools multifunction button.											
<b>Tool Enabled</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
The "Tool Enabled" output assignment will be active if the tool is enabled.											



Tool Running	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						

The “Tool Running” output assignment will be active while the tool is running.

Service Indicator	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						

The “Service Indicator” output assignment will be active if the system is in need of service.

ToolsNet Connected	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						

The “ToolsNet Connected” output assignment will be active if the controller has an active connection to a ToolsNet server.

Open Protocol Connected	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						

The “Open Protocol Connected” output assignment will be active if the controller has an active Open protocol connection.

PFCS Connected	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						

The “PFCS Connected” output assignment will be active if the controller has an active PFCS connection.

Running PSet Number	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√	√			

The “Running PSet Number” output assignment will output the current PSet number.

Running Job Number	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√	√			

The “Running Job Number” output assignment will output the current Job number.

External Controlled	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√						√	√	√

The “External Controlled” output assignment will reflect the state of an input. Use the “Input Bus”, “Input Element”, and “Input Bit” to specify the input to reflect.

Tool in CCW	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						

The “Tool In CCW” output assignment will be active if the tool is put into disassembly mode and inactive if the tool is in assembly mode.

Tool in CW	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						

The “Tool In CW” output assignment will be active when the is in assembly mode and inactive if the tool is put into disassembly mode.

Torque	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√				

If Stage Default is selected, the “Torque” output assignment will output the final torque value of the most recent rundown. If a specific Stage is selected, the “Torque” output assignment will output the final torque value of the selected stage. In both cases, the value will be cleared to 0 at the start of a new fastening cycle or a Job reset. At the end of the fastening cycle the final torque will be truncated to an integer and output.

# AcraDyne Gen IV iAC Controller Manual

<b>Torque (x10)</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√				
<p>If Stage Default is selected, the "Torque (x10)" output assignment will output the final torque value of the most recent rundown. If a specific Stage is selected, the "Torque (x10)" output assignment will output the final torque value of the selected stage. In both cases, the value will be cleared to 0 at the start of a new fastening cycle or a Job reset. At the end of the fastening cycle the final torque will be multiplied by 10, truncated to an integer and output.</p>											
<b>Torque (x100)</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√				
<p>If Stage Default is selected, the "Torque (x100)" output assignment will output the final torque value of the most recent rundown. If a specific Stage is selected, the "Torque (x100)" output assignment will output the final torque value of the selected stage. In both cases, the value will be cleared to 0 at the start of a new fastening cycle or a Job reset. At the end of the fastening cycle the final torque will be multiplied by 100, truncated to an integer and output.</p>											
<b>Angle</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√				
<p>If Stage Default is selected, the "Angle" output assignment will output the final angle value of the most recent rundown. If a specific Stage is selected, the "Angle" output assignment will output the final angle value of the selected stage. In both cases, the value will be cleared to 0 at the start of a new fastening cycle or a Job reset.</p>											
<b>Rundown Saved to FTP Server</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√				
<p>The "Rundown Saved to FTP Server" output assignment will output the ID of the last rundown that was saved to the FTP server.</p>											
<b>Fastener Removed</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The "Fastener Removed" output assignment will go active when a fastener is removed by the operator. The controller must be configured to report disassembly for this output to work. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>Spindle OK</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The "Spindle Ok" output assignment will go active at the completion of multi-spindle fastening if all spindles have an OK. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>Spindle NOk</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The "Spindle NOK" output assignment will go active at the completion of multi-spindle fastening if one or more of the spindles have an NOK. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>Spindle Fastening Complete</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The "Spindle Fastening Complete" output assignment will go active at the completion of multi-spindle fastening. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>Pulses</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√				√				
<p>The "Pulses" output assignment will output the pulse count value of the most recent rundown. The value will be cleared to 0 at the start of a new fastening cycle or a Job reset.</p>											

<b>Pulses High</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The “Pulses High” output assignment will go active at the completion of a fastening that has an pulse count that exceeds the high limit. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>Pulses Low</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The “Pulses Low” output assignment will go active at the completion of a fastening that has an pulse count that falls below the low limit. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>Pulses NOK</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The “Pulses Ok” output assignment will go active at the completion of a fastening that has an acceptable pulse count. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>Pulses Ok</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The “Pulses NOK” output assignment will go active at the completion of a fastening that has an unacceptable pulse count. It will go inactive when the next fastening is started (the torque exceeds the threshold value) or a Job reset.</p>											
<b>ON</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The “ON” output assignment will be active when the controller is powered up and remains active until power down.</p>											
<b>Job Aborted</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The “Job Aborted” output assignment will go active if a Job is aborted. It will go inactive when the job is reset.</p>											
<b>Tool In Use</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√	√					
<p>The “Tool In Use” output assignment will go active when the trigger is pressed, whereupon a timer will restart. It will go inactive when the specified time is reached without becoming active in between.</p>											
<b>Barcode Scanned</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The “Barcode Scanned” output assignment will go active when a barcode is scanned. The ID # (1-4) will activate the corresponding bit, if it is covered by the number of bits configured. The maximum size is 4 bits. All bits will go inactive when a tool reaches the InCycle threshold of a rundown or when they are reset.</p>											
<b>Start Trigger Active</b>	Bus	Element	Bit 0-32	Polarity N.O./N.C.	Mode: Normal, Timed, Flash	Time	Width	Offset	Input Bus	Input Element	Input Bit
	√	√	√	√	√						
<p>The ‘Start Trigger Active’ assignment will reflect the state of the active Start Input configured to run the tool.</p>											

Possible Start Inputs include:

- Start from IO
  - Start
  - Dual Start Interlocked
- Start from Tool Buttons
  - Lever and/or PTS
  - Dual Levers Interlocked
  - Start from Master Tool
  - Start from Remote Start
  - Latched Throttle
- Start Trigger Active is available for the iEC Controller Only.

## 12. Controller Supported MIDs

Supported MID			
MID	Description	Revisions	Note
1	Communication start	1,2,3	
2	Communication start acknowledge	1,2,3	
3	Communication stop		
4	Command error		
5	Command accepted		
8	Application data subscribe		Support MID 900 curve data only
9	Application data unsubscribe		Support MID 900 curve data only
10	Parameter set ID upload request		
11	Parameter set ID upload reply		
12	Parameter set data upload request		
13	Parameter set data upload reply		Always returns a batch size of 0
14	Parameter set selected subscribe		
15	Parameter set selected		
16	Parameter set selected acknowledge		
17	Parameter set selected unsubscribe		
18	Select Parameter set		
19	Set Parameter set batch size		
20	Reset Parameter set batch counter		
30	Job ID upload request		
31	Job ID upload reply		
34	Job info subscribe		
35	Job info		
36	Job info acknowledge		
37	Job info unsubscribe		
38	Select Job		
39	Job restart		
40	Tool data upload request	1,2	
41	Tool data upload reply		
42	Disable tool		
43	Enable tool		
50	Vehicle ID number download request		
51	Vehicle ID number subscribe	1,2	
52	Vehicle ID number	1,2	Has an option to send w/without IDs
53	Vehicle ID number acknowledge		
54	Vehicle ID number unsubscribe		
60	Last tightening result data subscribe	1-6,999	
61	Last tightening result data		
62	Last tightening result data acknowledge		
63	Last tightening result data unsubscribe		
64	Old tightening result upload request		

Supported MID			
MID	Description	Revisions	Note
65	Old tightening result upload reply		
70	Alarm subscribe		
71	Alarm		
72	Alarm acknowledge		
73	Alarm unsubscribe		
76	Alarm status		
77	Alarm status acknowledge		
80	Read time upload request		
81	Read time upload reply		
82	Set time		
90	Multi spindle status subscribe		
91	Multi spindle status		
92	Multi spindle status acknowledge		
93	Multi spindle status unsubscribe		
100	Multi spindle results subscribe		
101	Multi spindle results		
102	Multi spindle results acknowledge		
103	Multi spindle results unsubscribe		
113	Flash green light on tool		
127	Abort Job		
128	Job batch increment		
129	Job batch decrement		
130	Job off		
150	Identifier download request		
157	Reset all Identifiers		
200	Set external controlled relays		Only supports 0 (off) and 1 (on)
210	Status external monitored inputs subscribe		
211	Status external monitored inputs		
212	Status external monitored inputs acknowledge		
213	Status external monitored inputs unsubscribe		
214	IO device status request	1,2	
215	IO device status reply		
216	Relay function subscribe		See supported relay functions below.
217	Relay function		
218	Relay function acknowledge		
219	Relay function unsubscribe		
241	User data subscribe		Out_1 - Pulse status (0= OK, 1 = Low, 2 = High)
242	User data		
243	User data acknowledge		
244	User data unsubscribe		Out_2 - Pulses Out_3 - Undefined Out_4 - Undefined
900	Trace data		Trace type 1 & 2 only (angle & torque)
9999	Keep alive open protocol communication		


### Supported Relay Functions

Supported Relay Functions Number	Function
1	OK
2	NOK
5	Low Torque
6	High Torque
7	Low angle
8	High angle

Supported Relay Functions Number	Function
9	Cycle complete
10	Alarm
11	Batch NxOK
12	Job OK
19	Tool ready
20	Tool start switch

Supported Relay Functions Number	Function
21	Dir. switch = CW
22	Dir. switch = CCW
26	Tool running
145	Start Trigger Active
276	Cycle abort

## 13. Dimensions



## 14. Specifications

### Mechanical:

Dimensions	Width:	6.25 in	159 mm
	Height:	15.75 in	400 mm
	Depth:	12.5 in	316 mm
Weight:	Controller:	11 – 15 lbs depending on options	5 – 6.8 kg depending on options
	Plinth:	4.5 lbs	2 kg

### Operating Conditions:

Temperature:	32 to 122 °F (0 to 50 °C)
Humidity:	Non-condensing
Ingress Protection:	IP20

### Air Connections (models with internal shutoff valve and/or electronic regulator)

Supply Air Inlet:	130 PSI Maximum, Clean, Dry Air	Fitting Type: 1/2" NPT Female
Air Outlet to Tool		Fitting Type: 1/2" NPT Female
Exhaust		Fitting Type: 3/8" NPT Female

### Electrical:

AC Power Source: 100 - 240 VAC, 50/60 Hz, 1Amp, 100 Watts

### Standards Compliance

Contact AIMCO for details, 800-852-1368 or (503) 254-6600.

## 15. Troubleshooting

### **Issue: LED Frozen Showing "Initializing"**

**Solution:** The rear SD card containing the system UI may have become unseated. Turn off controller power. Depending on vintage, remove the label or cover plate to access the card slot. Gently depress the card and release to unseat it. Gently then press the card into the slot until feeling and hearing the locking click indicating it is secure. Replace the label or cover plate and power the controller back on.

### **Issue: System Port IP Connectivity using USB Cabling**

**Solution:** In most cases, connectivity will be automatic when connection between the controller SYSTEM PORT and a PC USB Port are made. Confirmation of the connection is noted by the presence of a USB Ethernet/RNDIS Gadget in the PC Adapter list. Should this connection not be established, specific instructions are located at the product manuals page at <https://www.aimco-global.com/manuals> under the heading **System Port Connectivity Troubleshooting for PCs**.

## 16. AIMCO Warranty

### **NEW TOOL AND ACCESSORY WARRANTY**

Any new tool or accessory branded with the AIMCO, Uryu, AcraDyne or Eagle Group name, and purchased from AIMCO, or through one of its authorized distributors or agents, is warranted to the original buyer against defects in materials and workmanship for a period of one (1) year\* from date of delivery. Under the terms of this warranty, AIMCO agrees, without charge, to repair or replace, at its option and Ex-Works (EXW) its authorized service centers, any product or accessory warranted hereunder proving to AIMCO's satisfaction to be defective as a result of defective workmanship or material. In order to qualify for this warranty, written notice to AIMCO must be given immediately upon discovery of such defect, at which time AIMCO will issue an authorization to return the tool. The defective item must be promptly returned to an authorized AIMCO service center with all freight charges prepaid.

### **REPAIRED TOOL WARRANTY**

Once a tool is beyond the new product warranty period as detailed above, AIMCO will provide repair subject to the following warranty periods: pneumatic tools: 90 days\*; electric tools and Acra-Feed: 90 days; battery tools: 30 days\*; DC Electric tools: 90 days\*

### **EXCLUSION FROM WARRANTY**

This warranty is valid only on products purchased from AIMCO, or through its authorized distributors or agents. AIMCO shall have no obligation pursuant to the AIMCO Warranty with respect to any tools or accessories which in AIMCO's sole judgment have been altered damaged, misused, abused, badly worn, lost or improperly maintained. This Warranty is null and void if the customer, or any other person other than an authorized representative of AIMCO, has made any attempt to service or modify the tool or accessory prior to its return to AIMCO under this Warranty.

The warranty provision with respect to each such product may be amended by AIMCO from time to time in its sole discretion. The liability of AIMCO hereunder shall be limited to replacing or repairing, at its option, any defective products which are returned freight pre-paid to AIMCO or, at AIMCO's option, refunding the purchase price of such products.

AIMCO reserves the right to make periodic changes in construction or tool design at any time. AIMCO specifically reserves the right to make these changes

without incurring any obligation or incorporating such changes or updates in tools or parts previously distributed.

THE AIMCO WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND AIMCO EXPRESSLY DISCLAIMS ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS WARRANTY SETS FORTH THE SOLE AND EXCLUSIVE REMEDY IN CONTRACT, TORT, STRICT LIABILITY, OR OTHERWISE.

THIS WARRANTY IS THE ONLY WARRANTY MADE BY AIMCO WITH RESPECT TO THE GOODS DELIVERED HEREUNDER, AND MAY BE MODIFIED OR AMENDED ONLY BY A WRITTEN INSTRUMENT SIGNED BY A DULY AUTHORIZED OFFICER OF AIMCO.

### **LIMITATION OF LIABILITY**

AIMCO'S LIABILITY PURSUANT TO WARRANTY OF THE PRODUCTS COVERED HEREUNDER IS LIMITED TO REFUND OF THE PURCHASE PRICE. IN NO EVENT SHALL AIMCO BE LIABLE FOR COSTS OF PROCUREMENT OF SUBSTITUTE GOODS BY THE BUYER. IN NO EVENT SHALL AIMCO BE LIABLE FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL OR OTHER DAMAGES (INCLUDING WITHOUT LIMITATION, LOSS OF PROFIT) WHETHER OR NOT AIMCO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSS, HOWEVER CAUSED, WHETHER FOR BREACH OR REPUDIATION OF CONTRACT, BREACH OF WARRANTY, NEGLIGENCE OR OTHERWISE. THIS EXCLUSION ALSO INCLUDES ANY LIABILITY WHICH MAY ARISE OUT OF THIRD PARTY CLAIMS AGAINST BUYER. THE ESSENTIAL PURPOSE OF THIS PROVISION IS TO LIMIT THE POTENTIAL LIABILITY OF AIMCO ARISING OUT OF THIS AGREEMENT AND/OR SALE.

**NOTE:** The AIMCO Warranty confers specific legal rights, however some states or jurisdictions may not allow certain exclusions or limitations within this warranty. **\*Note – All warranty periods addressed herein are determined using a standard shift, eight-hour work day.**



AIMCO CORPORATE HEADQUARTERS  
10000 SE Pine Street  
Portland, Oregon 97216  
Phone: (503) 254-6600  
Toll Free: 1-800-852-1368

AIMCO CORPORATION DE MEXICO SA DE CV  
Ave. Cristobal Colon 14529  
Chihuahua, Chihuahua. 31125  
Mexico  
Phone: (01-614) 380-1010  
Fax: (01-614) 380-1019