



Operating Instructions for

**Horizontal, Angle,
& Vertical
Grinders**

Die Grinders

It is the responsibility of the employer to place the information on this instruction sheet into the hands of the operator.



AIMCO tools have been designed with safety in mind. But it is still the responsibility of the user or service technician to insure that there is no misuse.

On the opposite page is a brief description of safe use practices when using grinders.

Always operate, inspect, and maintain this tool in accordance with American National Standards Institute Safety Code for Portable Air Tools (ANSI 13186.1) and any other applicable safety codes and regulations.

IMPORTANT

Make sure that these instructions are fully understood before operating this tool. The tool and its attachments and accessories must only be used for their designed purpose. For product liability and safety reasons, any modifications of the tool and its accessories must be agreed upon by the technical authority of the manufacturer. All locally legislated safety rules with regard to installation, operation, and maintenance shall be respected at all times.

INSTRUCTIONS FOR SAFE OPERATION

FIRST, follow your local safety regulations strictly on grinders and abrasives.



Ensure that the RPM of the grinder does not exceed the rated max. RPM of the wheel.

Remove the wheel before checking the RPM of the grinder.

Make sure that the rated speed marking on the tool is readable.



Ensure that the wheel is the correct fit for the grinder and that it is not damaged or worn.

The wheel should have correct hole dimensions and fit securely on the spindle.

Check that the flange and wheel combination correspond to national regulations.



After mounting the wheel, operate the grinder in a protected area to check that no failure occurs.

Keep the space around the grinder free from other people.



Use the recommended wheel guard. Ensure that it is not damaged and that the mountings are secure.

Never use a grinder without the wheel guard when the grinder wheel requires one.


The ANSI B7.1 safety code specifies that the grinding wheel must be used with a protective guard. Always use the wheel guard furnished with the grinder. Obtain a suitable guard from the manufacturer if you change the type of wheel being used.



Use personal protection equipment.

Avoid inhaling dust resulting from the grinding operation by using an approved dust mask or dust exhaust system.

When using wire brushes, wear goggles and clothing that offer protection from the thrown wires.



Ensure that pressure does not exceed 90 PSIG. Use a pressure regulator.



Keep loose clothing and long hair clear of the grinder.



Beware of run-on. Do not touch the tool, after turning it off, until it has stopped completely.



Turn off air supply before changing wheel or disconnecting hose. Beware of whipping air hose.

AIR SUPPLY



AIR HOSE SIZE:

Air Inlet		Air Hose
1/8" NPT air inlet	use	1/4" ID air hose
1/4" NPT air inlet	use	3/8" ID air hose
3/8" NPT air inlet	use	1/2" ID air hose

AIR PRESSURE: 90 PSI (6.5 kg/cm²) Air Pressure is recommended for the most efficient performance. Too high of air pressure will shorten the life of the tool.

LUBRICATION



FOR AIR MOTOR: Apply turbine oil before and after operation. (For example, **MOBIL TURBINE OIL #32, SHELL TURBINE OIL #32**, or equivalent.)

FOR BEARINGS: Apply recommended high-quality grease properly (for example, **SHELL ALVANIA NO.2, SHELL ALVANIAEP, MOBILPLEX 2, MOBILPLEX 47** or equivalent) once every three months. Lubrication should be performed by competent personnel during regular overhaul to maintain optimum performance.

FOR ANGLE GEARS: Apply recommended high-quality grease properly (for example, **SHELL ALVANIA NO.2, SHELL ALVANIAEP, MOBILPLEX 2, MOBILPLEX 47** or equivalent) once per month when used on single shift basis. Lubrication interval should be more frequent with multi-shift usage. Lubrication should be made through visible fitting. Excessive amounts of grease will cause slowing and/or overheating.

MAINTENANCE



DRY AND CLEAN AIR: Drain daily and install filter at or near the take-off point to prevent trouble from foreign matter.

AIR HOSE AND JOINTS: Use air hose (the shorter, the better), joints, and other fittings of good condition and of proper size to avoid pressure drop.

REGULAR OVERHAUL: At least once every three months, regular or periodical overhaul by a competent person is needed for best performance and trouble-free operation.

GENUINE PARTS: Use only AIMCO genuine spare parts for replacement.



Any repair of AIMCO tools must be completed by AIMCO or an authorized AIMCO Service Center. Contact AIMCO at (503) 254-6600 for an authorized Service Center in your area.



AIMCO CORPORATE HEADQUARTERS

10000 SE Pine Street
Portland, Oregon 97216
Phone: (503) 254-6600
Toll Free: 1-800-852-1368

AIMCO CHINA

Room 607, No. 3998 Hongxin Rd Dibao Plaza
Minhang District, Shanghai
China
Phone: 0086-21-34319246
Fax: 0086-21-34319245

AIMCO CORPORATION DE MEXICO SA DE CV

Ave. Cristobal Colon 14529
Chihuahua, Chihuahua. 31125
Mexico
Phone: (01-614) 380-1010
Fax: (01-614) 380-1019

AIMCO EUROPE

Avenida Rio Gallo, 431
19174 Galápagos - Guadalajara
Spain
Phone: + 34 673 34 99 25