


# SPCC-P120075DL SIGNATURE SERIES PISTOL TOOL

## EXPLODED VIEW

PAGE 1 of 2



### PARTS LIST — FOR REFERENCE ONLY

| Index Number | Part Number      | Description                         | Qty. | Index Number | Part Number      | Description                       | Qty. | Index Number | Part Number      | Description                        | Qty. |
|--------------|------------------|-------------------------------------|------|--------------|------------------|-----------------------------------|------|--------------|------------------|------------------------------------|------|
| 1            | 0-311026         | C type Retainer Ring S42            | 1    | 5            | 33251-GWC090H-05 | Steel Ball Seat                   | 1    | 19           | 33251-GWC090H-06 | Gear Plate                         | 1    |
| 2            | 33257-GWC090H-02 | Reaction Bar                        | 1    | 6            | 0-197001         | Wave Spring 35 x 27 x 8.381       | 1    | 20           | 0-511168         | Pin (5 x 17L)                      | 3    |
| 3            | 32049-GWC120H-01 | Internal Gear Assembly              | 1    | 7            | 0-231012         | Thrust Needle Bearing NTB2035+2AS | 1    | 21           | 0-511107         | Pin (1.5 x 10L)                    | 39   |
| 5            | 33249-GWC250H-04 | Internal Gear                       | 1    | 8            | 33251-GWC090H-04 | Clutch Gear                       | 1    | 22           | 33249-GWC090H-07 | Planet Gear                        | 3    |
| 6            | 33254-GWC250H-01 | Lock Nut                            | 1    | 9            | 33249-GWC090H-06 | Planet Gear                       | 3    | 23           | 33251-GWC090H-03 | Rotary Seat                        | 1    |
| 7            | 33251-GWC120H-01 | Gear Cage                           | 1    | 10           | 0-511161         | Pin (1.5 x 11.8L)                 | 51   | 25           | 33254-GWC090H-01 | Lock Nut                           | 1    |
| 8            | 33249-GWC120H-03 | Planet Gear                         | 3    | 11           | 0-511170         | Pin (7 x 22L)                     | 3    | 26           | 0-521010         | Steel Ball 5                       | 4    |
| 9            | 0-511070         | Pin (2 x 22L)                       | 54   | 16           | 32029-GWC090-01  | Clutch Assembly                   | 1    | 27           | 1100-507         | Spring                             | 4    |
| 10           | 33255-009        | Pin (10 x 34L)                      | 3    | 1            | 0-101062         | Cap Screw (M6 x P1 x 12L)         | 1    | 28           | 33239-GWC090H-01 | Washer 45 x 33 x 0.5t              | 1    |
| 11           | 0-201011         | Ball Bearing 688ZZ (16 x 8 x 5T)    | 1    | 2            | 33239-GWC090H-02 | Washer (6 x 16 x 2.15)            | 1    | 30           | 32051-GWC090H-01 | Fixing Seat Assembly               | 1    |
| 12           | 0-201104         | Ball Bearing 6908ZZ (62 x 40 x 12T) | 1    | 3            | 0-241003         | Thrust Ball Bearing CRT8-16       | 1    | 31           | 0-101071         | Cap Screw M4 x P0.7 x 16L          | 4    |
| 13           | 33242-GWC250H-01 | Bushing                             | 1    | 4            | 33229-GWC090H-01 | Upper Clutch Unit                 | 1    | 32           | 0-101008         | Cap Screw M4 x P0.7 x 25L          | 4    |
| 14           | 0-321027         | C type Retainer Ring R68            | 1    | 5            | 0-521005         | Steel Ball 3                      | 3    | 33           | 0-201058         | Ball Bearing 6804ZZ (32 x 20 x 7T) | 1    |
| 15           | 32049-GWC120-01  | Clutch Gear Assembly                | 1    | 6            | 33229-GWC090H-02 | Lower Clutch Unit                 | 1    | 34           | 33252-GWC090H-01 | Housing Cover                      | 1    |
| 1            | 0-321024         | C type Retainer Ring R39            | 1    | 7            | 33248-GWC090H-01 | Spring                            | 1    | 35           | 0-101005         | Cap Screw M4 x P0.7 x 6L           | 4    |
| 2            | 0-231013         | Thrust Needle Bearing NTA1625+2AS   | 1    | 8            | 33254-GWC090H-03 | Clutch Bolt                       | 1    | 36           | 32098-GWC120H-01 | Motor Housing Assembly             | 1    |
| 3            | 33249-GWC120H-01 | Clutch Central Gear                 | 1    | 9            | 33251-GWC090H-08 | Spring Seat                       | 1    | See Page 2   |                  |                                    |      |
| 4            | 0-521046         | Steel Ball 8                        | 3    | 17           | 33239-GWC090H-03 | Washer 43 x 18 x 2t               | 2    | 37           | 33239-GWC090H-04 | Washer 31.9 x 25 x 2.5t            | 1    |
|              |                  |                                     |      | 18           | 33249-GWC090H-05 | Central Gear                      | 1    | 38           | 140S-108         | Bushing                            | 2    |



10000 SE PINE  
PORTLAND, OR 97216  
503-254-6600  
FAX 503-255-2615


When ordering spare parts, please specify  
tool type, part number, and description.

REVISED 06/25

# SPCC-P120075DL SIGNATURE SERIES PISTOL TOOL

## EXPLODED VIEW - PAGE 2

Motor Housing Assembly



### PARTS LIST — FOR REFERENCE ONLY

| Index Number | Part Number      | Description                 | Qty. | Index Number | Part Number     | Description                | Qty. | Index Number | Part Number      | Description               | Qty. |
|--------------|------------------|-----------------------------|------|--------------|-----------------|----------------------------|------|--------------|------------------|---------------------------|------|
| 36           | 32098-GWC120H-01 | Motor Housing Assembly      | 1    | 11           | 32050-PWAP-03   | Gear Box Assembly          | 1    | 22           | B09IWT#B1        | F/R Valve (1 set x 2 pcs) | 1    |
| 1            | 0-151020         | Self-Tapping Screw M4 x 16L | 9    | 12           | 0-121005        | Cap Screw M4 x P0.7 x 10L  | 4    | 23           | D48IWT           | Spring                    | 1    |
| 2            | 33101-GWC090H-01 | Upper Housing               | 1    | 13           | 0-511050        | Pin (4 x 12.8L)            | 8    | 24           | 33110-NPA-02     | Cover                     | 1    |
| 3            | 32602-GWC090H-06 | Lower Housing               | 1    | 14           | 32083-GWC120-01 | Brushless Motor            | 1    | 25           | B86IWT           | Connector Wire            | 1    |
| 4            | 33249-GWC-01     | Gear Ring                   | 1    | 15           | 32076-GWC025-01 | LCM Board Assembly         | 1    | 26           | B86PW35          | Connector Wire            | 1    |
| 5            | 33239-PWAP-04    | Washer                      | 1    | 16           | 33110-NPA-01    | Cover                      | 1    | 27           | 32076-GWC-01     | PCB-Storage               | 1    |
| 6            | 33251-GWC090H-07 | Gear Cage                   | 1    | 17           | 0-152001        | Self-Tapping Screw 3 x 14L | 2    | 28           | 0-151018         | Self-Tapping Screw        | 4    |
| 7            | 33249-PWAP-09    | Planet Gear 23T (Rohs)      | 3    | 18           | 32076-NPA-02    | PC Board                   | 1    | 29           | 33249-GWC090H-08 | Central Gear              | 1    |
| 8            | 0-211003         | Needle Bearing KT-477       | 3    | 19           | B09PW#B1        | Trigger Assembly           | 1    |              |                  |                           |      |
| 9            | 0-511050         | Pin (4 x 12.8L)             | 3    | 20           | D48PW15         | Spring                     | 1    |              |                  |                           |      |
| 10           | 33239-PWAP-02B   | Washer 15.1 x 18.5 x 0.3t   | 1    | 21           | C39PW15-3       | Washer                     | 1    |              |                  |                           |      |



10000 SE PINE  
PORTLAND, OR 97216  
503-254-6600  
FAX 503-255-2615

When ordering spare parts, please specify  
tool type, part number, and description.