


BRH-1U, -1US, 1UG BABY RIVETING HAMMERS

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
705-982-1 HANDLE ASSEMBLY				707-001-1 HANDLE ASSEMBLY FOR BRH-1UG				ACCESSORIES			
1	705-011-2	Handle	1	17	970-226-0	Pin (H) (3 x 26)	1	44	705-546-1	Piston	1
2	705-102-1	Valve Bushing	1	18	973-124-0	Roll Pin (3 x 24)	1	45	705-567-1	Bushing (R)	1
3	719-108-1	Valve Plug	1	19	990-904-0	O-Ring (SNS-6)	1	46	786-567-1	Bushing (H)	1
4	705-107-1	Throttle Trigger	1					47	705-782-2	Exhaust Deflector	1
5	185-091-7	Air Inlet Bushing	1	20	707-010-2	Handle	1	48	980-010-0	Flat Head Notch (3)	1
6	976-129-0	Spring (6.5 x 21)	1	21	719-100-1	Valve	1	49	980-006-0	Round Head Notch (3)	1
7	981-207-0	Steel Ball (9/32)	1	22	719-102-1	Valve Bushing	1	50	980-005-0	Round Head Notch (2.5)	1
8	970-228-0	Pin (H) (3 x 28)	1	23	719-108-1	Valve Plug	1	BRH-1UG SERIES COMMON PARTS			
9	973-116-0	Roll Pin (3x16)	1	24	707-107-1	Throttle Trigger	1	40	705-195-1	Main Valve	1
706-002-1 HANDLE ASSEMBLY FOR BRH-1US				25	093-103-1	Valve Rad Bushing	1	41	705-196-1	Valve Box	1
10	706-011-2	Handle	1	26	976-116-0	Spring (6 x 32)	1	42	705-197-1	Valve Box Cover	1
11	705-102-1	Valve Bushing	1	27	970-534-0	Pin (H) (6 x 34.5)	1	43	705-286-1	Cylinder	1
12	601-108-1	Valve Plug	1	28	973-116-0	Roll Pin (3 x 16)	1				
13	418-107-1	Valve Lever	7								
5	185-091-7	Air Inlet Bushing	1								
14	706-106-1	Valve Rod cap	1								
15	976-114-0	Spring (6 x 18)	1								
16	981-207-0	Steel Ball (9/32)	1								



10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify tool type, part number, and description.

FOOTNOTES