UBX-T70 SHUT-OFF BATTERY PULSE TOOL

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.
1	12F-025-0	Handle	1
3	12F-079-0	Connector	1
4	147-107-2	Trigger	1
5	09B-212-5	Reverse Lever	1
6	12F-012-0	Body Cover	1
7	12F-013-0	Top Cover	1
8	12F-035-0	Connector	1
9	12F-036-0	Hammer Case Connector	1
10	12F-038-0	Slide Base	1
11	12F-439-0	Front Case	1
12	12F-867-0	Front Case Packing	1
13	12F-901-0	Liner Rear Plate	1
14	12F-310-0	Anvil Front Spacer	1
15	12A-902-5	Liner	1
16	12F-546-0	Piston	1
17	145-929-6	Check Valve Cover	1
18	12F-130-0	Operating Rod (1.8 x 65.5)	1
19	12F-319-0	Anvil	1
20	12A-440-5	Driving Blade (A)	1
21	12A-440-6	Driving Blade (B)	1
22	12F-835-0	Filter (K200)	1
23	12F-904-0	Front Liner Plate	1
24	12F-905-0	Liner Casing	1
25	12A-906-3	Liner Casing Cover	1
26	174-907-2	Relief Valve Spring	1
27	12F-970-0	Relief Valve	1
28	144-270-0	Pressure Valve	1
29	12A-276-5	Pressure Valve Body	1
30	194-742-0	Oil Plug	1
31	12F-924-0	Name Plate	1
32	12F-993-0	Plate (Specifications)	1
33	094-997-4	Plate (Others)	1
34	094-996-4	Plate (Caution)	1
35	861-181-1	Tapping Screw	5
36	910-383-0	Battery Terminal Block	1
37	910-404-0	Level Display Cover	1
38	910-484-0	Fan Assembly	1
39	910-449-0	Elastomer Tube (2)	2
40	910-468-0	LED Cover	1
41	910-475-0	Switch	1
42	910-476-0	Nylon Mesh	1
43	910-477-0	Mesh Plate	1
44	911-046-0	Battery Board Assembly	1
45	911-042-0	Motor Assembly (T type) (L=35)	1
46	863-890-1	Motor (T type)	1
47	863-891-1	Control Board with LED and Buzzer	1
48	944-203-0	Supporting Ring (3.1 x 5 x 1)	1
49	944-212-0	Backup Ring (12 x 16 x 1.5)	1
50	945-026-0	Allen Head Bolt (M4 x 16)	4
51	957-063-0	Allen Head Screw (M2 x 4)	2
52	961-009-0	Round Washer (M4) (8 x 0.5)	4
53	962-800-0	Wave Washer (BWW-625)	1
54	963-253-0	Tapping Screw (3 x 16)	6
55	969-449-0	Pin (G) (3 x 6)	1
56	970-013-0	Pin (H) (1.5 x 4)	1
57	970-014-0	Pin (H) (1.5 x 6.8)	2
58	970-147-0	Pin (H) (2.5 x 5)	2
59	972-033-0	Pin (2.5 x 8)	2
60	972-087-0	Pin (3 x 6)	4
61	973-014-0	Roll Pin (2 x 14)	1
62	973-018-0	Roll Pin (2 x 18)	1
63	974-952-0	Half-moon Key (3 x 12) (3)	1
64	974-961-0	Half-moon Key (1.5 x 15.8)	1
65	976-006-0	Spring (3 x 5) (0.4)	1
66	976-499-0	Spring (7.3 x 9.4) (0.4)	1
67	976-526-0	Spring (2.4 x 5.5) (0.26)	1
68	976-958-0	Spring (2.8 x 6.9) (0.4) n=6.25	1
69	976-966-0	Spring (3.3 x 9) (0.35)	1
70	981-001-0	Ball (3/32)	1
71	981-002-0	Ball (1/8)	1
72	981-225-0	Ball (2.5mm)	2
73	982-922-0	Ball Bearing 6901ZZ	2
74	990-334-0	O-Ring (JW1530-24)	1
75	990-621-0	O-Ring (3.8 x 1.8 x 1.0)	1
76	990-985-0	O-Ring (SNS-28) (NOK)	1
77	990-970-0	O-Ring (SNS-2) (NOK)	2
77-1	990-620-0	O-Ring 3.8 x 2.2 x 0.8 (Ro10)	1
78	992-020-0	SU-Ring Q12 (NTN)	1
79	996-280-0	Diaphragm	1
80	939-091-0	Allen Wrench (1.5)	1
81	975-798-0	Adjusting Spacer 24 x 18 x t	1
82	975-172-0	Spacer 24 x 18 x 1	1
PARTS FOR UBX-T70-RF8			
98	863-980-1	Washer	2
99	10E-924-7	Name Plate	1
100	863-974-1	Insulating Sheet	1
101	863-984-1	Body Cover	1
102	863-985-1	Wireless Board	1
103	911-043-0	Spacer (C-26025.5)	2
104	911-044-0	Spacer (C-2611)	2
105	861-436-1	Tapping Screw (2.6 x 16)	2
106	963-256-0	Tapping Screw (2.6 x 25)	2
107	863-952-1	Wireless Board Cable	1
STANDARD ACCESSORIES			
80	939-091-0	Allen Wrench (1.5) (80X20)	1
OPTIONAL ACCESSORIES			
	12F-840-0	Handle Protector (Standard)	1
	12F-840-1	Handle Protector (RF8)	1

FOOTNOTES

AIMCO
10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify tool type, part number, and description.